

# User Guide

## Thunderbolt® NTP Time Server TS200

*For use with: Thunderbolt® NTP Time Server TS200 (P/N 111224-50)  
Firmware version 1.0.0.0*

Version IND8 - March 2018  
Part Number 106131-50



# Legal Notices

## Corporate Office

Trimble Inc.  
935 Stewart Drive  
Sunnyvale, California 94085 United  
States of America.  
[www.trimble.com](http://www.trimble.com)  
Email: [tsgsupport@trimble.com](mailto:tsgsupport@trimble.com)

## Copyright and Trademarks

© 2018, Trimble Inc.

Trimble and the Globe & Triangle logo are trademarks of Trimble Inc., registered in the United States and in other countries. Thunderbolt is a trademark of Trimble Inc..

Microsoft, Windows, and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

All other trademarks are the property of their respective owners.

## Release Notice

This is the March 2018 release of the Thunderbolt® NTP Time Server Clock, part number 111224-00.

## The Australian Consumer Law

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Trimble's warranty (set out below) is in addition to any mandatory rights and remedies that you may have under the Australian Consumer Law.

## LIMITED WARRANTY TERMS AND CONDITIONS

### Product Limited Warranty

Subject to the following terms and conditions, Trimble Inc. ("Trimble") warrants that for a period of one (1) year from date of purchase this Trimble product (the "Product") will substantially conform to Trimble's publicly available specifications for the Product and that the hardware and any storage media components of the Product will be substantially free from defects in materials and workmanship..

### Product Software

Product software, whether built into hardware circuitry as firmware, provided as a standalone computer software product, embedded in flash memory, or stored on magnetic or other media, is licensed solely for use with or as an integral part of the Product and is not sold. If accompanied by a separate end user license agreement ("EULA"), use of any such software will be subject to the terms of such end user license agreement (including any differing limited warranty terms, exclusions, and limitations), which shall control over the terms and conditions set forth herein.

Except for the limited license rights expressly provided herein, Trimble and its suppliers have and will retain all rights, title and interest (including, without limitation, all patent, copyright, trademark, trade secret and other intellectual property rights) in and to the Product Software and all copies, modifications and derivative works thereof (including any changes which incorporate any of your ideas, feedback or suggestions).

You shall not (and shall not allow any third party to): (a) decompile, disassemble, or otherwise reverse engineer the Product Software or attempt to reconstruct or discover any source code, underlying ideas, algorithms, file formats or programming interfaces of the Product Software by any means whatsoever (except and only to the extent that applicable law prohibits or restricts reverse engineering restrictions); (b) distribute, sell, sublicense, rent, lease, or use the Product Software (or any portion thereof) for time sharing, hosting, service provider, or like purposes; (c) remove any product identification, proprietary, copyright, or other notices contained in the Product Software; (d) modify any part of the Product Software, create a derivative work of any part of the Product Software, or incorporate the Product Software into or with other software, except to the extent expressly authorized in writing by Trimble; (e) attempt to circumvent or disable the security key mechanism that protects the Product Software against unauthorized use (except and only to the extent that applicable law prohibits or restricts such restrictions); or (f) publicly disseminate performance information or analysis (including, without limitation, benchmarks) from any source relating to the Product Software. If the Product Software has been provided to you as embedded in any hardware device, you are not licensed to separate the Product Software from the hardware device. If the Product Software has been provided to you separately from a hardware device but is intended to be loaded onto a hardware device specified by Trimble (such as a firmware update), your license is limited to loading the Product Software on the device specified by Trimble, and for no other use.

### Software Fixes

During the limited warranty period you will be entitled to receive such Fixes to the Product software that Trimble releases and makes commercially available and for which it does not charge separately, subject to the procedures for delivery to purchasers of Trimble products generally. If you have purchased the Product from a Trimble authorized dealer rather than from Trimble directly, Trimble may, at its option, forward the software Fix to the Trimble authorized dealer for final distribution to you. Minor Updates, Major Upgrades, new products, or substantially new software releases, as identified by Trimble, are expressly excluded from this update process and limited warranty. Receipt of software Fixes or other enhancements shall not serve to extend the limited warranty period. For purposes of this warranty the following definitions shall apply: (1) "Fix(es)" means an error correction or other update created to fix a previous software version that does not substantially conform to its Trimble specifications; (2) "Minor Update" occurs when enhancements are made to current features in a software program; and (3) "Major Upgrade" occurs when significant new features are added to software, or when a new product containing new features replaces the further development of a current product line. Trimble reserves the right to determine, in its sole discretion, what constitutes a Fix, Minor Update, or Major Upgrade.

### Warranty Remedies

If the Trimble Product fails during the warranty period for reasons covered by this limited warranty and you notify Trimble of such failure during the warranty period, Trimble will repair OR replace the nonconforming Product with new, equivalent to new, or

reconditioned parts or Product, OR refund the Product purchase price paid by you, at Trimble's option, upon your return of the Product in accordance with Trimble's product return procedures then in effect.

#### How to Obtain Warranty Service

To obtain warranty service for the Product, please contact your local Trimble authorized dealer. Alternatively, you may contact Trimble to request warranty service by sending an email to [tsgsupport@trimble.com](mailto:tsgsupport@trimble.com). Please prepare to provide:

- your name, address, and telephone numbers
- proof of purchase
- a copy of this Trimble warranty
- a description of the nonconforming Product including the model number
- an explanation of the problem

The customer service representative may need additional information from you depending on the nature of the problem. **Any expenses incurred in the making of a claim under this warranty will be borne by you.**

#### Warranty Exclusions and Disclaimer

This Product limited warranty shall only apply in the event and to the extent that: (a) the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Trimble's applicable operator's manual and specifications, and; (b) the Product is not modified or misused.

This Product limited warranty shall not apply to, and Trimble shall not be responsible for, defects or performance problems resulting from: (i) the combination or utilization of the Product with hardware or software products, information, data, systems, interfaces, or devices not made, supplied, or specified by Trimble; (ii) the operation of the Product under any specification other than, or in addition to, Trimble's standard specifications for its products; (iii) the unauthorized installation, modification, or use of the Product; (iv) damage caused by: accident, lightning or other electrical discharge, fresh or salt water immersion or spray (outside of Product specifications), or exposure to environmental conditions for which the Product is not intended; (v) normal wear and tear on consumable parts (e.g., batteries); or (vi) cosmetic damage. Trimble does not warrant or guarantee the results obtained through the use of the Product, or that software components will operate error free.

**NOTICE REGARDING PRODUCTS EQUIPPED WITH TECHNOLOGY CAPABLE OF TRACKING SATELLITE SIGNALS FROM SATELLITE BASED AUGMENTATION SYSTEMS (SBAS) (WAAS/EGNOS, AND MSAS), OMNISTAR, GPS, MODERNIZED GPS OR GLONASS SATELLITES, OR FROM IALA BEACON SOURCES: TRIMBLE IS NOT RESPONSIBLE FOR THE OPERATION OR FAILURE OF OPERATION OF ANY SATELLITE BASED POSITIONING SYSTEM OR THE AVAILABILITY OF ANY SATELLITE BASED POSITIONING SIGNALS.**

THE FOREGOING LIMITED WARRANTY TERMS STATE TRIMBLE'S ENTIRE LIABILITY, AND YOUR EXCLUSIVE REMEDIES, RELATING TO THE TRIMBLE PRODUCT UNDER THIS LIMITED WARRANTY. EXCEPT AS OTHERWISE EXPRESSLY PROVIDED HEREIN, THE PRODUCT, AND ACCOMPANYING DOCUMENTATION AND MATERIALS ARE PROVIDED "AS-IS" AND WITHOUT EXPRESS OR IMPLIED WARRANTY OF ANY KIND, BY EITHER TRIMBLE OR ANYONE WHO HAS BEEN INVOLVED IN ITS CREATION, PRODUCTION, INSTALLATION, OR DISTRIBUTION, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OR GUARANTEES OF MERCHANTABILITY, ACCEPTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NONINFRINGEMENT. THE

STATED EXPRESS WARRANTIES ARE IN LIEU OF ALL OBLIGATIONS OR LIABILITIES ON THE PART OF TRIMBLE ARISING OUT OF, OR IN CONNECTION WITH, ANY PRODUCT. BECAUSE SOME STATES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON DURATION OR THE EXCLUSION OF AN IMPLIED WARRANTY, THE ABOVE LIMITATION MAY NOT APPLY OR FULLY APPLY TO YOU.

#### Limitation of Liability

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, TRIMBLE'S ENTIRE LIABILITY UNDER ANY PROVISION HEREIN SHALL BE LIMITED TO THE AMOUNT PAID BY YOU FOR THE PRODUCT AND IN NO EVENT SHALL TRIMBLE OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGE WHATSOEVER UNDER ANY CIRCUMSTANCE OR LEGAL THEORY RELATING IN ANYWAY TO THE PRODUCTS, SOFTWARE AND ACCOMPANYING DOCUMENTATION AND MATERIALS, (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF DATA, OR ANY OTHER PECUNIARY LOSS), REGARDLESS OF WHETHER TRIMBLE HAS BEEN ADVISED OF THE POSSIBILITY OF ANY SUCH LOSS AND REGARDLESS OF THE COURSE OF DEALING WHICH DEVELOPS OR HAS DEVELOPED BETWEEN YOU AND TRIMBLE. BECAUSE SOME STATES AND JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY OR FULLY APPLY TO YOU.

**PLEASE NOTE: THE ABOVE TRIMBLE LIMITED WARRANTY PROVISIONS WILL NOT APPLY TO PRODUCTS**

**PURCHASED IN THOSE JURISDICTIONS (E.G., MEMBER STATES OF THE EUROPEAN ECONOMIC AREA) IN WHICH PRODUCT WARRANTIES ARE THE RESPONSIBILITY OF THE LOCAL TRIMBLE AUTHORIZED DEALER FROM WHOM THE PRODUCTS ARE ACQUIRED. IN SUCH A CASE, PLEASE CONTACT YOUR LOCAL TRIMBLE AUTHORIZED DEALER FOR APPLICABLE WARRANTY INFORMATION.**

#### Official Language

THE OFFICIAL LANGUAGE OF THESE TERMS AND CONDITIONS IS ENGLISH. IN THE EVENT OF A CONFLICT BETWEEN ENGLISH AND OTHER LANGUAGE VERSIONS, THE ENGLISH LANGUAGE SHALL CONTROL.

#### Registration

To receive information regarding updates and new products, please contact your local Trimble authorized dealer or visit the Trimble website at [www.trimble.com/register](http://www.trimble.com/register). Upon registration you may select the newsletter, upgrade, or new product information you desire.

#### Notices

Class B Statement – Notice to Users. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes and modifications not expressly approved by the manufacturer or registrant of this equipment can void your authority to operate this equipment under Federal Communications Commission rules.

#### Canada

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the radio interference regulations of the Canadian Department of Communications, ICES-003.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de Classe B prescrites dans le règlement sur le brouillage radioélectrique édicté par le Ministère des Communications du Canada, ICES-003.

#### Europe

This product has been tested and found to comply with the requirements for a Class B device pursuant to European Council Directive 89/336/EEC on EMC, thereby satisfying the requirements for CE Marking and sale within the European Economic Area (EEA). These requirements are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential or commercial environment.



#### Notice to Our European Union Customers

For product recycling instructions and more information, please go to [www.trimble.com/ev.shtml](http://www.trimble.com/ev.shtml).

Recycling in Europe: To recycle Trimble WEEE (Waste Electrical and Electronic Equipment, products that run on electrical power.), Call +31 497 53 24 30, and ask for the "WEEE Associate". Or, mail a request for recycling instructions to:

Trimble Europe BV  
c/o Menlo Worldwide Logistics Meerheide 45  
5521 DZ Eersel, NL



#### Declaration of Conformity

We, Trimble Inc.,

935 Stewart Drive  
Sunnyvale, CA 94085-3913  
United States of America  
+1-408-481-8000

declare under sole responsibility that the product: Thunderbolt® NTP Time Server Clock complies with Part 15B of FCC Rules.

Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

# List of Abbreviations

A-GPS	Assisted GPS
C/No	Carrier-to-Noise power ratio
DC	Direct Current
DOP	Dilution of Precision
EGNOS	European Geostationary Navigation Overlay Service
ESD	Electrostatic Discharge
GLONASS	Globalnaya Navigatsionnaya Sputnikovaya Sistema
GND	Ground
GNSS	Global Navigation Satellite Systems
GPS	Global Positioning System
I/O	Input / Output
LNA	Low Noise Amplifier
NMEA	National Marine Electronics Association
NTP	Network Time Protocol. Common time distribution over networks.
OCXO	Oven Controlled Crystal Oscillator
OD mode	Over-determined clock mode
PoE	Power over Ethernet
PCB	Printed Circuit Board
PDOP	Position Dilution of Precision
PPS	Pulse per Second
QZSS	Quasi-Zenith Satellite System
RF	Radio Frequency
TCXO	Temperature Controlled Crystal Oscillator
ToD	Time of Day
T-RAIM	Timing Receiver Autonomous Integrity Monitoring
T-SUTC	Universal Time Coordinated
VCC	Voltage at the Common Collector; positive supply voltage
VSWR	Voltage Standing Wave Ratio

# Safety Information

## Warnings and Cautions

An absence of specific alerts does not mean that there are no safety risks involved. Always follow the instructions that accompany a Warning or Caution. The information they provide is intended to minimize the risk of personal injury and/or damage to the equipment. In particular, observe safety instructions that are presented in the following formats:

**WARNING** – *A Warning alerts you to a likely risk of serious injury to your person and/or damage to the equipment.*

**CAUTION** – *A Caution alerts you to a possible risk of damage to the equipment and/or loss of data.*

**CAUTION** – *Electrical hazard – risk of damage to equipment. Make sure all electrostatic energy is dissipated before installing or removing components from the device. An electrostatic discharge (ESD) can cause serious damage to the component once it is outside the chassis*

## Operation and storage

**WARNING** – *Operating or storing the Thunderbolt® NTP Time Server Clock outside the specified temperature range can damage it. For more information, see the product specifications on the data sheet.*

**WARNING** – *The Thunderbolt® NTP Time Server Clock is only to be used in a restricted access location*

**WARNING** – *Short-circuit (overcurrent) protection device required. The Thunderbolt® NTP Time Server Clock relies on the building's installation for short-circuit (overcurrent) protection. Ensure that the protective device is listed rated not greater than 10A*

## Routing any cable

**CAUTION** – *Be careful not to damage the cable. Take care to avoid sharp bends or kinks in the cable, hot surfaces (for example, exhaust manifolds or stacks), rotating or reciprocating equipment, sharp or abrasive surfaces, door and window jambs, and corrosive fluids or gases.*

# Table of Contents

## Contents

Legal Notices .....	2
List of Abbreviations .....	5
Safety Information .....	6
Warnings and Cautions .....	6
Operation and storage .....	6
Routing any cable .....	6
Table of Contents .....	7
Chapter 1: Product Overview .....	15
1.1 Product Overview .....	16
1.2 Key Features .....	16
1.3 Physical Specifications .....	16
1.4 Performance .....	17
1.5 Front Panel Elements .....	17
EIA-232 Serial Port .....	17
Sync Out .....	17
Status LED .....	17
Management Port (LAN) .....	17
Ethernet Port .....	17
SFP Port .....	17
1.6 Back Panel Elements .....	18
GNSS Antenna Connection .....	18
Power Input .....	18
Alarm Relay .....	18
Grounding .....	18
1.7 Use and care .....	18
1.8 Technical assistance .....	19
Chapter 2: Installation .....	21
2.1 Getting Started .....	22

2.2 Mounting the Device to a Rack .....	22
2.3 Connecting Power .....	22
Grounding the Device .....	23
Powering-Up .....	23
2.4 GNSS Considerations.....	23
Selecting Site for GNSS Antenna .....	24
2.5 Communication Ports .....	25
Serial Port.....	25
Management Ethernet Port.....	26
NTP Electrical Ethernet Port .....	26
NTP SFP Ethernet Port .....	26
2.6 Status LED .....	27
Chapter 3: GNSS Antenna .....	29
3.1 GNSS Antenna .....	30
Antenna requirements.....	30
3.2 Antenna Placement.....	30
Sky-Visibility .....	30
Multipath-reflections .....	31
Jamming.....	31
Ground Plane .....	31
GNSS Antenna Cabling .....	31
Lightning Considerations.....	32
Chapter 4: Command Line Interface Reference .....	33
4.1 CLI Overview .....	34
4.2 Command User Levels.....	34
4.3 Command Line Format.....	34
4.4 CLI Command Set .....	35
4.4.1 get alarm .....	35
4.4.2 set alarm .....	35
4.4.3 view alarm.....	36
4.4.4 view access.....	36
4.4.5.0 get auth .....	36
4.4.5.1 get auth local.....	36

4.4.5.2 get auth tacacs .....	37
4.4.5.3 get auth radius .....	37
4.4.6.0 set auth .....	37
4.4.6.1 set auth radius .....	38
4.4.6.2 set auth tacacs .....	38
4.4.6.3 set auth local .....	39
4.4.6.4 set auth type .....	40
4.4.7 get auto .....	41
4.4.8 set auto .....	41
4.4.9.0 config .....	41
4.4.9.1 config firmware .....	42
4.4.9.2 config firmware list .....	42
4.4.9.3 config firmware stage .....	42
4.4.9.4 config firmware update .....	43
4.4.9.5 config firmware unstage .....	43
4.4.9.6 config load .....	44
4.4.9.7 config list .....	44
4.4.9.8 config save .....	44
4.4.9.9 config system .....	45
4.4.10 get comm .....	45
4.4.11 set comm .....	45
4.4.12 get date .....	46
4.4.13 get dlog .....	46
4.4.14 set dlog .....	46
4.4.15 download .....	47
4.4.16 get freq .....	47
4.4.17 set freq .....	47
4.4.18 view freq .....	48
4.4.19 get gnss .....	48
4.4.20 set gnss .....	48
4.4.21 view gnss .....	49
4.4.22 help .....	50
4.4.23 howto .....	50

4.4.24 get input.....	51
4.4.25 set input .....	51
4.4.26 view input.....	52
4.4.27 view logs.....	53
4.4.28 get network.....	54
4.4.29 set network .....	54
4.4.30 view network .....	55
4.4.31 get ntp.....	56
4.4.32 set ntp .....	56
4.4.33 view ntp.....	57
4.4.34 get output .....	58
4.4.35 set output.....	58
4.4.36 get periodic .....	59
4.4.37 set periodic.....	59
4.4.38 ping.....	59
4.4.39 ping6 .....	60
4.4.40 view pos .....	60
4.4.41 view prodconf .....	60
4.4.45 quit .....	61
4.4.46 view realtime .....	61
4.4.47 help set.....	61
4.4.48 get snmp .....	61
4.4.49 set snmp.....	62
4.4.50 view summary.....	62
4.4.51 view stream.....	62
4.4.52 get syslog.....	63
4.4.53 set syslog.....	63
4.4.54 view temp .....	64
4.4.55 get time .....	64
4.4.56 view uptime .....	64
4.4.57 get user .....	64
4.4.58 set user.....	65
4.4.59 set user logout .....	66

4.4.60 view user .....	66
4.4.61 view version .....	66
4.4.62.0 view .....	67
4.4.62.1 view gnss stream.....	68
4.4.62.2 view dlog .....	68
4.4.63 whatif .....	68
4.5 List of “How to” help topics .....	68
4.5.1 How to get current Alarm status?.....	69
4.5.2 How to set alarm of level major, alarm number 2 with setTime as 2 and clearTime as 1?.....	69
4.5.3 How to disable Ethernet port 0/1? .....	69
4.5.4 How to set ip address of 192.168.0.9, and also set a netmask and a gateway address on ethernet 0 port?.....	69
4.5.5 How to set bnc output of even? .....	69
4.5.6 How to set periodic output of period 2 and value 1? .....	69
4.5.7 How to set serial port baud rate to 19200bps? .....	69
4.5.8 How to add a new user called trimble1 with an access level of user? .....	70
4.5.9 How to delete an existing user trimble?.....	70
4.5.10 How to change user password? .....	70
4.5.11 How to restore factory default settings? .....	70
4.5.12 How to reboot the system? .....	70
4.6 List of “What if” help topics .....	71
4.6.1 What if you have an FPGA-Load-Bad alarm.....	71
Chapter 5: Web Interface .....	73
5.1 Home Page .....	74
Refresh Rate.....	74
5.2 Login Page .....	75
5.3 System Page .....	76
5.4 System Status.....	76
Alarms and Events - Alarms .....	76
Alarms and Events – Event Log.....	77
System Info .....	78
Timing Status.....	79
NTP Status.....	81

GNSS Receiver Status .....	82
Satellite Data .....	83
Network eth0 .....	84
Network eth1 .....	85
Network Management Port .....	86
Ethernet Statistics .....	87
5.5 Interface Management .....	88
IP Assignment eth0 .....	88
IP Assignment eth1 .....	89
IP Assignment management port .....	90
VLAN eth0 .....	91
VLAN eth1 .....	92
SNMP Configuration Basic .....	93
SNMP Configuration v2c .....	94
Syslog .....	95
Serial Port.....	96
5.6 Synchronization Management.....	97
NTP Time Server eth0 .....	97
NTP Time Server eth1 .....	98
NTP Time Server - NTP security .....	99
NTP Time Server - NTP Peers .....	100
GNSS Receiver .....	101
Output Configuration.....	102
5.7 Security Management.....	103
User Management - Active Sessions.....	103
User Management - User Accounts .....	104
User Management – Password Rules .....	105
Authentication Portal.....	106
Authentication RADIUS .....	107
Authentication TACACS+.....	108
5.8 System Management .....	109
Alarm Configuration.....	109
System Configuration.....	110

System Software Upload.....	111
Chapter 6: SNMP Support.....	113
6.1 SNMP Overview .....	114
6.2 SNMP Traps.....	114
6.3 Accessing the SNMP MIB Files .....	114
Chapter 7: TS200 Provisioning .....	115
7.1 Help Commands.....	116
7.1.1 help set.....	116
7.1.2 help set ntp .....	117
7.2 View System and Hardware Version.....	119
7.2.1 view version .....	119
7.2.2 view prodconf .....	120
7.3 View Alarms, Status and Firmware .....	121
7.3.1 get alarm .....	121
7.3.2 view logs.....	122
7.4 GNSS and Lock Status.....	124
7.4.1 view gnss .....	124
7.4.2 get gnss .....	125
7.4.3 view freq .....	126
7.5 Network Configuration .....	127
7.5.1 get network.....	127
7.5.2 set network .....	128
7.5.3 get network eth<x> .....	129
7.5.4 view network eth<x> .....	130
7.6 VLAN Configuration.....	131
7.6.1 set network eth0 vlan .....	131
7.6.2 get network eth0.....	132
7.6.3 set network eth0.20.....	133
7.6.4 get network eth0.....	134
7.8 Input Clock Source Control .....	135
7.8.1 get input.....	135
7.8.2 set input .....	135
7.8.3 view input.....	136

7.9 Antenna Cable Delay and BNC Port Output.....	137
7.9.1 set gnss adelay 40 .....	137
7.9.2 set output 10Mhz.....	138
7.9.3 config firmware list .....	139
Chapter 8: VLANs .....	141
8.1 VLANs Overview .....	143
8.2 Configuring VLAN support with CLI commands .....	143
8.3 Configuring VLAN with Web Interface .....	144
8.4 Configuring one VLAN ID.....	145
8.5 Adding another VLAN ID .....	146
8.6 Procedure to remove all VLAN IDs.....	148
Appendix A: SNMP Traps .....	150
Appendix B: Alarms.....	154
Contact Information.....	162

## Chapter 1: Product Overview

In this chapter:

Operation

Key Features

Getting started

Use and care

Technical assistance

The Thunderbolt® NTP Time Server Clock TS200 is a NTP Time Server. It provides very accurate NTP time reference.

The *Thunderbolt® NTP Time Server Clock TS200's User Guide* describes how to integrate and operate the Trimble® Thunderbolt® NTP Time Server Clock TS200.

For more information on GPS, go to <http://www.trimble.com/gps/index.shtml>.

## 1.1 Product Overview

Trimble's Thunderbolt® NTP Time Server Clock TS200 is a high quality NTP Time Server Clock with an integrated Trimble GNSS receiver with the best accurate and reliable technology. The Thunderbolt® TS200 is designed and optimized for low latency applications such as high frequency trading, providing the highest performance to meet the stringent time & phase requirements.

It provides NTP timing protocol. Thunderbolt® TS200 uses GNSS (Global Navigation Satellite Systems) signals from GPS, GLONASS, Galileo, and Beidou as the primary time source for synchronization.

Thunderbolt® TS200 can use its built-in, disciplined OCXO (oven controlled crystal oscillator) as autonomous time base for providing several hours of accurate holdover in case that GNSS signals are not available.

Hardware redundancy can be achieved by using two Thunderbolt® NTP Time Server clocks.

Thunderbolt® TS200 comes in a rack-mountable enclosure; two Thunderbolt® TS200 units fit side-by-side in a 1RU height 19" rack.

## 1.2 Key Features

- Network Time Server (NTP v4)
- Multi-GNSS Receiver (GPS, GLONASS, Beidou and Galileo)
- 1 RJ45 Dedicated Management Port
- 1 RJ45 Port (NTP)
- 1 SFP interface (NTP)
- 1 BNC interface (PPS/10MHz outputs)
- IPv4, IPv6 and VLAN
- 1 EIA-232 (RS-232) Serial Port
- Small foot print – ½ Rack 1U
- CLI / SNMP traps
- DC (default) and AC power options

## 1.3 Physical Specifications

The Thunderbolt® TS200 can be installed in a 19-inch rack mount unit. It can fit in ½ rack space, 2 Thunderbolt® TS200 units can be installed side-by-side in a full rack space for additional redundancy.

## 1.4 Performance

The system level performance is defined by the total number of packets per second. The total/maximum number of packets per second supported is 6,272.

Thunderbolt® NTP Time Server TS200 can support 2,500 NTP transactions per second.

## 1.5 Front Panel Elements



### ***EIA-232 Serial Port***

The EIA-232 (RS-232) serial port provides a craft interface to the Thunderbolt® NTP Time Server TS200 through an EIA-232 female connector.

### ***Sync Out***

The Thunderbolt® TS200 features a BNC female connector that provides 1PPS output. It can be configured for 10MHz, see the set output command.

### ***Status LED***

The Thunderbolt® NTP TS200 provides 4 LEDs on the front panel that indicate the following status:

- Power
- Antenna
- Sync
- Status/Alarm

### ***Management Port (LAN)***

The Thunderbolt® TS200 has one dedicated management Ethernet port. The RJ-45 port provides connectivity to Ethernet LAN for the configuration of the unit.

### ***Ethernet Port***

One RJ45 Ethernet port. Provides NTP connectivity to Ethernet Networks

### ***SFP Port***

One SFP port. Provides NTP connectivity to Ethernet Networks.

## 1.6 Back Panel Elements



### *GNSS Antenna Connection*

The Thunderbolt® NTP Time Server TS200 features an SMA connector for the antenna input to the embedded GNSS receiver

### *Power Input*

The standard input power is -48VDC. The Thunderbolt® TS200 provides a 5pole terminal block to connect dual DC power inputs.

### *Alarm Relay*

The Thunderbolt® TS200 provides a 3.81mm 3pin terminal header for dry relay connection. Both Normally Open (NO) and Normally Closed (NC) connections are available to the user. Relay closure is considered **closed** in Critical alarm condition.

### *Grounding*

The frame ground connection on Thunderbolt® TS200 is available through a M5 Grounding Terminal Stud.

## 1.7 Use and care

The Thunderbolt® TS200 is a high-precision electronic instrument and should be treated with reasonable care. Thunderbolt® TS200 typically doesn't need any care after the first setup. Should you need to clean the unit, use a dry non-static tissue or a light moist tissue for removing dust or stain from the enclosure. Make sure that no water enters the Thunderbolt® TS200 enclosure anywhere. Don't use solvents, aggressive or abrasive cleaning agents anywhere on the Thunderbolt® TS200 device.

**CAUTION – There are no user-serviceable parts inside the Thunderbolt® NTP Time Server Clock TS200 and any modification to the unit by the user voids the warranty.**

## 1.8 Technical assistance

If you have a problem and cannot find the information you need in the product documentation, contact the Trimble Technical Assistance Center at 800-767-4822 or email

[tgsupport@trimble.com](mailto:tgsupport@trimble.com).



## Chapter 2: Installation

In this chapter:

Getting Started

Time References

Operation

Timing module Performance

Holdover

Customization

This chapter describes the procedure for installing the Thunderbolt® NTP Time Server Clock TS200.

## 2.1 Getting Started

This section explains how to install and configure the Thunderbolt TS200.

Unpack and inspect the content of package. The following items are included in the standard box:

- Thunderbolt NTP Time Server Clock TS200
- Mounting brackets and installation accessories
- Dummy plate for single unit installation in 19" rack

## 2.2 Mounting the Device to a Rack

The Thunderbolt NTP TS200 should be installed indoor or outdoor in an environmental controlled cabinet. The Thunderbolt TS200 will install in an EIA standard 19-inch rack. The unit occupies ½ rack space and if required two TS200 units can be installed side-by-side.

*NOTE – It is recommended that 1 rack-unit of space (1.75 in) be kept empty above the device. This allows a small amount of convectional airflow. Forced airflow is not required.*



## 2.3 Connecting Power

The Thunderbolt TS200 supports single or dual redundant AC or DC power supplies. The Thunderbolt TS200 standard option is 48VDC. The Thunderbolt TS200 is capable of operating from -36Vdc to -72Vdc at a maximum current level of 250mA.

The DC input is reverse polarity protected. Reversing polarity with 48VDC options will not cause damage to the unit and the unit will operate normally.

*NOTE – The power cable should be routed separately from the data (signal) cables.*

## ***Grounding the Device***

The Thunderbolt TS200 M5 Terminal Stud on the back panel is used for grounding.

The Thunderbolt TS200 is suitable for connection to the Central Office and CPE. The Time Server Clock shall be located in a restricted access location where only crafts personnel are allowed access.

The Thunderbolt TS200 shall be grounded via a copper ground conductor. The unit shall be installed and connected to the common bonding network (CBN).

All bare grounding connection points to the Thunderbolt TS200 shall be cleaned and coated with an anti-oxidant solution before connections are made.

All surfaces on the Thunderbolt TS200 that are un-plated shall be brought to a bright finish and treated with an anti-oxidant solution before connection is made.

All non-conductive surfaces on the Thunderbolt TS200 shall be removed from all threads and connection points to ensure electrical continuity

The Thunderbolt TS200 DC power returns shall be treated as DC-I (Isolated from Frame Ground).

Thunderbolt TS200 requires a ring terminal with a 14-AWG wire that utilizes 15in-lbs to secure to primary ground.

## ***Powering-Up***

After verification of the input power source, switch on the power supply to the Thunderbolt TS200. The Green Power LED should turn ON.

## **2.4 GNSS Considerations**

See the next chapter for a full description of how to choose the correct antenna cable/antenna combination.

When connected to a GNSS antenna the Thunderbolt TS200 can receive GNSS signal without user intervention– the factory default is GPS and GLONASS. The user can enable Beidou in place of GLONASS or enable single constellation mode.

The Trimble family of Bullet antennas is best matched with Thunderbolt TS200. The bullet antenna has following versions:

- Bullet III GPS only antenna
- Bullet GG GPS and GLONASS antenna
- Bullet L1/L2 GPS Dual Band – L1 and L2 frequencies
- Bullet 40dB GPS L1 high gain (40dB) antenna
- Bullet GB GPS and Beidou antenna
- Bullet 360 GPS, GLONASS, Beidou and Galileo antenna

Connecting the GNSS antenna will turn the Antenna LED Green.

### ***Selecting Site for GNSS Antenna***

It is important that the GNSS antenna has the fullest possible view of the sky. In most cases, this means installing the antenna on a high point, such as roof top. Avoid overhanging objects such as trees and towers. Also take care to place the antenna away from low lying objects such as neighboring buildings that may block a portion of the sky near the horizon. If a full view of the sky is not possible, mount the antenna aiming towards the Equator to maximize the southern view of the sky (choose a northern view in the Southern Hemisphere).

Use the criteria below to select a good outdoor site for the GPS antenna. The best locations provide:

- Unobstructed views of the sky and horizon.
- Low electro-magnetic interference (EMI) and radio frequency interference (RFI) – away from high-power lines, transmitting antennas, and powerful electrical equipment.
- Convenient access for installation and maintenance.
- Reasonable access for the antenna cable to reach the Thunderbolt TS200

## 2.5 Communication Ports

The Thunderbolt TS200 has four communications ports on the front panel.

- 1 Serial Port (RS232)
- 1 Management Port Ethernet (eth2) 10/100/1000 Base-T (RJ-45)
- 1 NTP Time Server Port Ethernet (eth1) 10/100/1000 Base-T (RJ-45)
- 1 NTP Time Server Port SFP (Small Form-Factor Pluggable)

Either Serial port or Ethernet eth2 (RJ-45) is the dedicated management port to configure the Thunderbolt NTP Time Server TS200.

### Serial Port

A bi-directional EIA standard RS-232 is located on the front panel. The serial port provides access to command line interface (CLI) for limited status and configuration of the Thunderbolt TS200.




Figure 2.1: Serial Port pin assignments

Use a straight through cable with following setting:

Data Rate	115200 baud
Parity	None
Data Bits	8
Stop Bits	1

### Serial Port Pin Assignment

Pin	RS-232 Signal	Description on Echo Side
1	DCD	Not Used
2	RxD	Data Transmit
3	TxD	Data Receive
4	DTR	Not Used
5	GND	Ground
6	DSR	Not Used
7	RTS	Not Used
8	CTS	Not Used
9	RI	Not Used

### **Management Ethernet Port**

The Thunderbolt TS200 supports one 10/100/1000 Base-T Ethernet port that allows connection to standard CAT-5 / CAT-5e / CAT-6 cables with RJ-45 male connector.

The Ethernet port features an LED that indicates the state of the port. The port is designated as “Ethernet-2”. The user can use this port to gain access to the Web interface (HTTPS) or command line interface (TELNET/SSH).

The factory default settings for the Ethernet-2 network port are as follows:

- IP Address: 192.168.2.250
- Mask: 255.255.255.0
- Gateway: 0.0.0.0

### **NTP Electrical Ethernet Port**

The Thunderbolt NTP TS200 supports one 10/100/1000 Base-T Ethernet port that allows connection to standard CAT-5 / CAT-5e / CAT-6 cables with RJ-45 male connector.

The Ethernet port features an LED that indicates the state of the port. The port is designated as “Ethernet-1”. This port is not designed for communication purposes for security reasons. This port is designed for providing NTP.

The factory default settings for the Ethernet-1 network port are as follows:

- IP Address: 192.168.1.250
- Mask: 255.255.255.0
- Gateway: 0.0.0.0

***NOTE – The Ethernet interface shall not be connected to a cable longer than 6 meters. If a distance greater than 6 meters is required, then the Ethernet interface shall be connected to a switch to comply with GR-1089.***

### **NTP SFP Ethernet Port**

The Thunderbolt NTP Time Server Clock TS200 supports one 10/100/1000 Base-T Ethernet port that allows connection to standard CAT-5 / CAT-5e / CAT-6 cables with electrical SFP or fiber cables with optical SFP.

The Ethernet port features an LED that indicates the state of the port. The port is designated as “Ethernet-0”. This port is not designed for communication purposes for security reasons. This port is designed for providing NTP.

The factory default settings for the Ethernet-0 network port are as follows:

- IP Address: 192.168.0.250
- Mask: 255.255.255.0
- Gateway: 0.0.0.0

## 2.6 Status LED

Alarm and status information is presented through the use of four LEDs. All LEDs have corresponding dry contact relay outputs at the back side of the Thunderbolt® TS200 device.

LED	Color	Indication	Meaning
Power	Green	ON	System is powered on
		OFF	System does not have power
ANT	Green	ON	Reference acquired & tracking
		Blinking, 1/2Hz	Reference being acquired, or no computing
		OFF	No reference active or antenna
Sync	Green	ON	Locked
		Blinking, 1/2Hz	Acquisition or Holdover
		OFF	Free-run or startup
Status	Red	OFF	No active alarms
		ON	Critical Alarm
		Blink, 1Hz	Minor alarm condition
		Blink, 1/2Hz	Major alarm condition



## Chapter 3: GNSS Antenna

### In this chapter:

- Antenna Requirements
- OPEN/SHORT Detection
- Antenna Placement
- Multipath
- Jamming
- Ground plane

A good GNSS antenna, together with a good installation site, is the key for getting the best performance from a GNSS receiver. This chapter explains the requirements for the antenna and provides recommendations for a good installation.

## 3.1 GNSS Antenna

The antenna receives the GNSS satellite signals and passes them to the receiver. The GNSS signals are spread spectrum signals in the 1551MHz to 1614MHz range and do not penetrate conductive or opaque surfaces. Therefore, the antenna must be located outdoors with a clear view of the sky. The internal GNSS receiver requires an active antenna with integrated LNA. The received GNSS signals are very low power, approximately -130dBm, at the surface of the earth. Trimble's active antenna includes a preamplifier that filters and amplifies the GNSS signals before delivery to the receiver.

The onboard circuits provide DC supply voltage on the SMA coax connector for the external, active GNSS antenna. The antenna supply voltage is fully protected against short circuit by the onboard Open/Short detection with integrated current limiter. The Thunderbolt TS200™ has a full antenna monitoring circuit on board.

### *Antenna requirements*

The Thunderbolt TS200™ requires an active GNSS antenna with built-in Low-Noise Amplifier (LNA) for optimal performance. The antenna LNA amplifies the received satellite signals for two purposes:

- a) Compensation of losses on the cable
- b) Lifting the signal amplitude in the suitable range for the receiver frontend.

Task b) requires an amplification of at least 15dB, while 20dB is the sweet spot for the Thunderbolt TS200™. This would be the required LNA gain if the antenna was directly attached to the receiver without cable in between.

The cable and connector between the antenna and the receiver cause signal loss. The overhead over the minimum required 15 dB and the actual LNA gain of the antenna is available for task a). So in case of a 30dB LNA gain in the antenna, 15 dB are available for compensating losses.

Or in other words, the attenuation of all elements (cables and connectors) between the antenna and the receiver can be up to a total of 15dB with a 30dB LNA. With a different antenna type, take the difference between 15dB and the antenna's LNA gain as the available compensation capability. Subtract the insertion losses of all connectors from the 15dB (or whatever the number is) and the remainder is the maximum loss, which your cable must not exceed.

As the GNSS signals are hidden in the thermal noise floor, it is very important that the antenna LNA doesn't add more noise than necessary to the system; therefore a low noise figure is even more important than the absolute amplification.

Trimble does not recommend having more than 35dB remaining gain (LNA gain minus all cable and connector losses) at the antenna input of the receiver module. The recommended range of remaining LNA gain at the connector of the receiver module is 20dB to 30dB with a minimum of 15dB and a maximum of 35dB.

## 3.2 Antenna Placement

### *Sky-Visibility*

GNSS signals can only be received on a direct line of sight between antenna and satellite. The antenna should see as much as possible of the total sky. Seen from the northern hemisphere of the earth, more satellites will

be visible in the southern direction rather than in northern direction. The antenna should therefore have open view to the southern sky. If there are obstacles at the installation site, the antenna should be placed south of the obstacles, preferably, in order not to block sky-view to the south.

If the installation site is in the southern hemisphere of the earth, then the statements above are reversed – more satellites will be visible in the northern direction. Near to the equator, it doesn't matter.

Partial sky visibility causes often poor DOP values due to the geometry of the visible satellites in the sky. If the receiver can only see a small area of the sky, the DOP has a high degree of uncertainty and will be worse compared to a condition with better geometric distribution. It may happen that a receiver is seeing 6 satellites, all close together, and still get a much worse DOP than a receiver which sees 4 satellites, but all in different corners of the sky. The receiver's DOP filter rejects fixes with high DOP (high uncertainty), therefore it can take longer to get the first acceptable fix if sky visibility is partly obstructed.

### ***Multipath-reflections***

Multipath occurs when the GNSS signals are reflected by objects, such as metallic surfaces, walls and shielded glass for example. The antenna should not be placed near a wall, window or other large vertical objects if it can be avoided.

### ***Jamming***

Jamming occurs when the receiver function is disturbed by external RF sources that interfere with GNSS signals or saturate the antenna LNA or receiver front-end. A good indicator to detect jamming is switching off all other equipment except the GNSS. Watch the satellite signal levels in this condition. Then switch on other equipment and see if the signal levels go down. A drop of signal levels indicates interference to GNSS from the other equipment. This method cannot, however, detect all possible kinds of jamming. Spurious events are hard to catch. Low frequency fields, like 50 Hz, are unlikely to jam the receiver. Broadband sparks are a potential source of spurious jamming. There's no general installation rule or specification though, because the effect of jamming highly depends on the nature of the jamming signal and there are uncountable many variations possible, so that it's not possible to standardize a test scenario.

### ***Ground Plane***

A metal plate or surface under the antenna can block signal reflections from below. This is a good method to mitigate reflections, if the receiver is mounted on high masts or other elevated sites.

### ***GNSS Antenna Cabling***

Trimble recommends low loss coaxial cabling.

Using any length of coaxial cable will add some time delay to the GNSS signal, which affects the absolute accuracy of the computed time solution. The time delay is dependent on the type of dielectric material in the cable and ranges from 3.3 to 6.5ns/meter.

The Antenna Cable Delay advances the Hardware Clock slightly to cancel out the signal delay caused by the length of the GPS antenna cable. To calculate the adjustment, select the signal propagation rate for the appropriate cable type and multiply it by the length of the cable.

For example, the standard RG-59 antenna cable has a propagation rate of 4.07ns/meter. The delay for a 25-meter cable will be 101.75ns (25 x 4.07 =101.75).

The outer shield on the GNSS cable shall be grounded to the chassis via the cable shell to the connector ground on the chassis. The connector ground is tied to the chassis. The chassis is connected to the primary ground which utilizes a ring terminal with a 14AWG wire connected to the rack. There are to be no breaks in the outer shield of the GNSS cable. Reference ANSI/NFPA 70, the National Electrical Code (NEC), in particular Section 820.93.

*NOTE – The GNSS antenna cable should only be connected when the unit is properly Earth grounded.*

### ***Lightning Considerations***

Although, it is not possible to protect the antenna from a direct lightning strike, the connected devices can be protected from secondary effects through protection devices.

Trimble recommends installing an in-line lightning arrestors in the antenna line to protect the receiver and connected devices. In-line lightning arrestors are mounted on a low impedance ground between the antenna and the point where the cable enters the building.

## Chapter 4: Command Line Interface Reference

In this chapter:

[CLI Overview](#)

[CLI Command Set](#)

This chapter describes the CLI command conventions, prompts, features and command syntax used in Thunderbolt® NTP Time Server Clock TS200.

## 4.1 CLI Overview

The Command Line Interface (CLI), also called the ASCII command set, can be used to control the Thunderbolt® TS200 from a terminal connected to the RS-232 serial port, or the Ethernet port via Telnet/SSH access.

## 4.2 Command User Levels

The Thunderbolt® TS200 provides a hierarchy of CLI users that permit an increasing level of access to system parameters.

- **User:** This is the basic login level. The login id for this level is “trimble”. This only allows for viewing of status, nothing can be changed other than their password
- **Admin:** this is the next level. The login id for this level is “trimbleadmin”. This user can configure everything about the unit except user accounts.
- **Supervisor:** This is the highest level. The login id for this level is “trimblesuper”. This allows configuration of everything, including user accounts. This is the Trimble user access level by default.

The passwords of each default user is the same as the lower-case user login id, for user level “trimbleadmin” the password is “trimbleadmin”.

## 4.3 Command Line Format

The command line format is as follows:

[action] command [parameter] [data] enter ( ↵) The type of

action to be taken with a command

- **Config** enables you to configure the device parameters
- **Get** allows you to retrieve specific information
- **Set** allows you to provision a specific parameter
- **View** enables you to display system information. This information cannot be altered by the user.

Help is available on the following topics:

- **help intro** an introduction to the Thunderbolt® TS200
- **help commands** a list of CLI commands available
- **help syntax** description of the syntax used in help descriptions
- **help howto** a list of "how to" help topics
- **help whatif** a list of "what if" help topics
- **help alarm** a descriptive list of possible alarm conditions within the system

Help on an individual command is available by typing help and the command name. For example, "help view".

***NOTE – The Thunderbolt TS200 has an extensive on-line, user level context aware, help system. The on-line help for the most part is more up-to-date and accurate than the information in the user guide.***

## 4.4 CLI Command Set

This section provides an alphabetical listing and details of all CLI commands. This section describes the topic “help commands”.

### 4.4.1 get alarm

The *get alarm* command retrieves information about the current system alarm configuration.

Command Syntax:

```
get alarm [ <n> [<n>] . . . ]↵
```

- <n> Alarm number to get configuration. More than one alarm number can be passed. If none given, then the configuration of all alarms is sent.

Level: User, Admin and Supervisor

### 4.4.2 set alarm

The *set alarm* command allows configuration of the system alarms. This is a multi-option command of the format:

Command Syntax:

```
set alarm <n> <level> <settime> <clrtime>↵
```

Where:

<n> The alarm number, this can be viewed with the 'get alarm' command

<level> Alarm level. One of:

IGN: This alarm condition is ignored. No indication given.

NFY: This alarm condition is a notification only.

MIN: This is a minor alarm condition.

MAJ: This is a major alarm condition.

CRI: This is a critical alarm condition.

<settime> Alarm set time. This is the time, in seconds, that the alarm condition must be active before the alarm is actually set. Range is 0 - 86400 (1 day)

<clrtime> Alarm clear time. This is the time, in seconds, that the alarm condition must be inactive before it the alarm is actually cleared. Range is 0 - 86400 (1 day)

**NOTE – For any entry, but default and <n>, a '-' character may be used to retain the current setting for that particular entry.**

Level: Admin and Supervisor

### 4.4.3 view alarm

The *view alarm* command displays the currently active alarms within the system. If there is no active alarm, then the command returns “No active alarms”.

Command Syntax:

```
view alarm <n> <all> ↵
```

Where:

<n>	The alarm number to view
<all>	view all alarms

Level: User, Admin and Supervisor

### 4.4.4 view access

This command shows access level of current logged in user.

Command Syntax:

```
view access ↵
```

Level: User, Admin and Supervisor

### 4.4.5.0 get auth

Return the current authentication settings. You can query specific settings with the options:

Syntax:

```
get auth <options> ↵
```

Where <options> are:

local	Get the local authentication settings
tacacs	Get the TACACS+ authentication settings
radius	Get the RADIUS authentication settings

Level: Supervisor

### 4.4.5.1 get auth local

Return the current settings for the local authentication parameters.

Syntax:

```
get auth local ↵
```

Level: Supervisor

#### 4.4.5.2 *get auth tacacs*

Return the current TACACS+ authentication settings.

Syntax:

```
get auth tacacs ↵
```

Level: Supervisor

#### 4.4.5.3 *get auth radius*

Return the current RADIUS authentication settings.

Syntax:

```
get auth radius ↵
```

Level: Supervisor

#### 4.4.6.0 *set auth*

The *set auth* command allows to change the authentication settings.

Command Syntax:

```
set auth <options> ↵
```

Where <options> are:

default	Set the authentication to the default settings
type [options]	Set the authentication type options. Please see ' <i>help set auth type</i> ' for additional information
radius [options]	Set the RADIUS authentication options. Please see <i>help set auth radius</i> for additional information.
Tacacs [options]	Set the TACACS+ authentication options. Please see <i>help set auth tacacs</i> for additional information.

***NOTE – Authentication <options> cannot be combined on one line, all command variants must be presented separately.***

Level: Supervisor

#### 4.4.6.1 set auth radius

The *set auth radius* command configures the RADIUS server connection information.

Command Syntax:

```
set auth radius (options)↵
```

Where the options are:

default	Set the RADIUS server information to defaults.
addr	Set the primary server address for the RADIUS server.
saddr	Set the secondary server address for the RADIUS server.
port	Set the IP port for the RADIUS server (same for primary and secondary).
secret	Set the shared secret value for the RADIUS server (same for primary and secondary). This may contain any 'printable' character. It is recommended that, the string be enclosed in "" to allow setting of characters that might be interpreted as parameter separators
timeout	Set the RADIUS server timeout value. 1-60 seconds

Level: Supervisor

#### 4.4.6.2 set auth tacacs

The *set auth tacacs* command configure the TACACS+ server connection information.

Command Syntax:

```
set auth tacacs (options)↵
```

Where the options are:

default	Set the TACACS+ server information to defaults
addr	Set the primary server address for the TACACS+ server.
saddr	Set the secondary server address for the TACACS+ server.
port	Set the IP port for the TACACS+ server (same for primary and secondary).
secret	Set the shared secret value for the TACACS+ server (same for primary and secondary). This may contain any 'printable' character. It is recommended that, the string be enclosed in "" to allow setting of characters that might be interpreted as parameter separators.
service	Set the TACACS+ server service string.
protocol	Set the TACACS+ server protocol string.
timeout	Set the RADIUS server timeout value. 1-60 seconds

Level: Supervisor

### 4.4.6.3 set auth local

The *set auth local* command allows to configure the local password configuration requirements.

Command Syntax:

```
set auth type [local [<options>]↵
```

minlen <n>	establishes a measure of complexity related to the password length (more in a moment on this). Range: 2 < minlen < 30
lcredit <n>	sets the minimum number of required lowercase letters. Range:  lcredit  < 6
ucredit <n>	sets the minimum number of required uppercase letters Range:  ucredit  < 6
dcredit <n>	sets the minimum number of required digits Range:  dcredit  < 6
ocredit <n>	sets the minimum number of required other characters. These characters can be any printable character, except for space. Range:  ocredit  < 6
difok <yes no>	sets if the user is required to enter a different password when changing their password (default 'yes')
pre <o>	Set a 'preconfigured' password criteria, where <o> is: p0 : require a minimum of 6 characters, no other requirements (default) p1 : require at least 1 uppercase letter. The password must be at least 6 characters long. p2 : require at least 1 uppercase and 2 lowercase letters. The password must be at least 6 characters long. p3 : require at least 1 uppercase, 2 lowercase, and 1 number. The password must be at least 6 characters long. p4 : require at least 1 uppercase, 2 lowercase, 1 number and 1 'other' character. The password must be at least 6 characters long.

'minlen' is actually a measure of complexity, not simply length. It specifies a complexity score that must be reached for a password to be deemed as acceptable. If each character in a password added one to the complexity count, then minlen would simply represent the password length but, if some characters count more than once, the calculation is more complex. So let's see how this works.

The minlen complexity measure is calculated in a number of steps:

- every character in a password yields one point, regardless of the type of character
- every lowercase letter adds one point, up to the value of lcredit
- every uppercase letter adds one point, up to the value of ucredit
- every digit adds one point, up to the value of dcredit
- every special character adds one point, up to the value of ocredit

If lcredit, ucredit, dcredit and ocredit were all set to 0, only the password length would be used to determine if it's acceptable. No characters would add extra points to the complexity score.



This is a 'set' function and the only way to remove a portal assignment from an authentication type is by assigning that to another authentication type. That means that the settings of one type may alter the settings of another type as only one authentication type may be enabled per portal. That means that if you issue:

```
set auth type local ssh
set auth type radius ssh
```

SSH will be using RADIUS authentication, not 'local'.

Examples:

```
set auth type local telnet
set auth type disable telnet
set auth type radius ssh,web
```

Level: Supervisor

#### 4.4.7 get auto

Show the current status of the auto-logout setting for this session. Default is to automatically log off this port after approximately 5 minutes of inactivity.

Command Syntax:

```
get auto ↵
```

#### 4.4.8 set auto

Control the auto-logout setting for this session. This allows the port to remain active even beyond the 5-minute timeout period of inactivity. This is effective only for this session (not stored). Default is 'on'.

This is useful when combined with 'view realtime' setting to allow monitoring of events.

Command Syntax:

```
set auto [on | off] ↵
```

Example:

```
set auto off
```

#### 4.4.9.0 config

Use the *config* command to view, change and select Thunderbolt® TS200 configuration.

Command Syntax:

```
config <list/ load / save/ firmware/system> ↵
```

- **config list**            output configuration as a list of 'set' commands
- **config load**            load Thunderbolt® TS200 configuration previously dumped
- **config save**            Reconfigure to the factory settings
- **config firmware**        utilities to handle firmware updates and loading
- **config system**         restart or reboot system

**NOTE – Config firmware option is available only at the supervisor level.**

Level: Admin and Supervisor

#### 4.4.9.1 *config firmware*

Use the *config firmware* command to maintain the firmware versions used by the Thunderbolt® TS200.

Command Syntax:

```
config firmware <list/stage/unstage/update> ↵
```

Additional help on each of the commands is available.

Level: Supervisor

#### 4.4.9.2 *config firmware list*

Use the *config firmware* command to view the currently available firmware packages on the Thunderbolt® TS200.

Command Syntax:

```
config firmware list <refresh> ↵
```

Where:

*<refresh>* to rescan of the images available on the system

The list will show a unique ID for the firmware and the firmware file name. The ID is to be used to refer to the firmware in the 'config firmware update' command.

Level: Supervisor

#### 4.4.9.3 *config firmware stage*

Use the *config firmware stage* command to put the firmware into system to allow updating (or rolling back) firmware versions.

Command Syntax:

```
config firmware stage [tftp <ipaddr><fname>] ↵
```

Where:

*tftp* to retrieve the firmware.

Note that the Thunderbolt TS200 GM200 is not running a tftp server. The user must have a tftp server, with the firmware desired, available to use this option.

*<ipaddr>* The IP address of the tftp server.

*<fname>* The filename of the update package to load from the server

*unlock* Use this option (by itself) to unlock the staging. This may be necessary in the event that a web page has started the upload process but was abandoned before being complete.

If 'tftp' is not used, then the system will use X-Modem protocol to load the firmware.

**NOTE – X-Modem is available only on serial port connections, and through telnet or SSH connections.**

*NOTE – The firmware package can be updated through Web interface which will be familiar to users.*

Examples include:

```
config firmware unlock ↵  
(unlock an abandoned staging process)
```

```
config firmware stage ↵  
(X-Modem transfer from serial port)
```

```
config firmware stage tftp 10.1.1.1 patchFile.tar.gz ↵  
(tftp transfer of 'patchFile.tar.gz ' from server 10.1.1.1)
```

Level: Supervisor

#### **4.4.9.4 config firmware update**

Use the *config firmware update* command to update the firmware on the Thunderbolt® TS200.

Command Syntax:

```
config firmware update <id> ↵
```

Where:

<id>            One of the IDs as given with the 'config firmware list' command

*NOTE – The firmware update will cause a restart of the system, which will cause a loss of network timing output.*

Level: Supervisor

#### **4.4.9.5 config firmware unstage**

Use the *config firmware unstage* command to remove the firmware load from the Thunderbolt® TS200 for use by *config firmware update* command.

Command Syntax:

```
config firmware unstage <id> ↵
```

Where:

<id>            One of the IDs as given with the 'config firmware list' command

*NOTE – After a firmware load is unstaged the <id> values will change so you will need to use 'config firmware list' to view the new firmware load IDs.*

Level: Supervisor

#### 4.4.9.6 config load

Use the *config load* command to reset Thunderbolt® TS200's configuration. This command expects a list of configuration settings as generated by "config list" command.

Command Syntax:

```
config load [ user / factory ] ↵
```

If no options are given this command will present a prompt for an upload as generated by the 'config list' commands.

If one of the options is given, then the appropriate settings will be loaded.

*NOTE – For security reasons, the list command and subsequent upload cannot be used to restore user settings*

*IMPORTANT NOTE!– If the factory settings are loaded then the all users are removed and the 'trimble' user restored*

Examples include:

```
config load ↵
```

```
config load user ↵
```

Level: Admin and Supervisor

#### 4.4.9.7 config list

Use the *config list* command to output Thunderbolt® TS200's configuration as a list of CLI commands.

Command Syntax:

```
config list ↵
```

You can make a backup of TS200's configuration by issuing a list command and using copy and paste in your window to save the configuration to a file on your local PC. You can restore the configuration by opening a CLI session, issue a 'config load' command and then "pasting" the list of commands saved earlier.

*NOTE 1 – For security reasons, the list command and subsequent upload cannot be used to restore user settings*

*NOTE 2 – The list command and subsequent upload cannot be used to restore the network settings.*

Level: Admin and Supervisor

#### 4.4.9.8 config save

Use the *config save* command to save the current settings of the Thunderbolt® TS200 to the user settings.

Command Syntax:

```
config save ↵
```

Level: Admin and Supervisor

#### 4.4.9.9 config system

Use the *config system* command to restart or reboot the system.

Command Syntax:

```
config system <options> ↵
```

Where <options> is one of:

- reboot      completely reboot the system. This performs a hardware reset of the system. This is very similar to the 'restart' option with the only real difference being that the entire system is restarted, which means that all drivers, etc are restarted on the system.
  
- debuglog    download a debug file for Trimble engineering. This file will be sent with the Z-Modem protocol. Send the resultant file to Trimble support when requested to aid in debugging of issues.

Level: Supervisor

#### 4.4.10 get comm

The *get comm* command retrieves the current communication port settings.

Command Syntax:

```
get comm ↵
```

Level: User, Admin and Supervisor

#### 4.4.11 set comm

The *set comm* command configures the communication port settings.

Command Syntax:

```
set comm [default] [ baud < baud> ] ↵
```

***NOTE – The default must be used by itself and restores the comm settings to their default values. The default baud rate is 115.2kbps-8-N-1***

Where:

<baud>      The baud rate, valid rates are:  
9600, 19200, 38400, 57600, 115200 and 230400

***NOTE – The setting does not affect the baud rate of the port if there is currently a user logged into that port. The port baud rate will change once the user is logged out.***

Examples include:

```
set comm default ↵  
set comm baud 19200 ↵
```

Level: Admin and Supervisor

#### 4.4.12 get date

The *get date* command retrieves the current system date.

Command Syntax:

```
get date [full] ↵
```

If the option 'full', is given this returns both the date and time.

```
get date full ↵
```

Use the *get date full* command to retrieve the current system date and UTC time. The format of the output is:

```
B d Y [hh:mm:ss]
```

Where:

B	is the full month string
d	is the day of month (00-31)
Y	is the full year, including century
hh:mm:ss	is returned only with the 'full' option

Level: User, Admin and Supervisor

#### 4.4.13 get dlog

The *get dlog* command retrieves the current data logger configuration.

Command Syntax:

```
get dlog ↵
```

Level: User, Admin and Supervisor

#### 4.4.14 set dlog

The *set dlog* command allows for starting or stopping the datalogging process.

Command Syntax:

```
set dlog start [holdover] | stop ↵
```

Where:

start	Start the datalogger, if no holdover option is given then the logging will not perform holdover cycling.
holdover	Reserved, do not use.
stop	Stop the datalogger.

Level: User, Admin and Supervisor

#### 4.4.15 download

The *download* command to download log files from the current system TS200.

Usage:

```
download [ sats | pos | freq ] ↵
```

Options:

sats Download TEXT logfile of the satellites the receiver has been tracking over time.  
pos Download TEXT logfile of position information of the receiver over time.  
freq Download TEXT logfile of the oscillator statistics over time.

#### 4.4.16 get freq

The *get freq* command retrieves the current operating mode of the control system.

Command Syntax:

```
get freq ↵
```

Level: User, Admin and Supervisor

#### 4.4.17 set freq

The *set freq* command sets the current operating mode of the control system. This command is only for test purposes and is not meant to be used in normal operation.

*NOTE: This is not a 'setting' like other commands. The operational mode of the control system is not stored as part of the unit configuration.*

Command Syntax:

```
set freq [halt | hold | lock | resync] ↵
```

Where:

- <halt> Put the control loop into User Halt mode. In this mode the frequency offset is 'frozen' and no computed compensation of the oscillator performance is used.
- <hold> Put the control loop into User Hold mode. In this mode, the frequency offset is compensated with computed oscillator performance. If there is no data available to perform a holdover then this is the same as 'User Halt'.
- <lock> Return the unit to normal operation. This does not command the unit to 'Lock' mode immediately, it merely takes it out of 'User Hold' or 'User Halt' and is not a mechanism to override the operation of the control system.
- <resync> Command the unit to force the output PPS to align with the current reference immediately. Note that this can cause jumps in time.

Example:

*set freq hold*

*set freq lock*

#### **4.4.18 view freq**

The *view freq* command displays the current frequency control information.

Command Syntax:

*view freq <stream> ↵*

If the option “stream” is given, then the measurements will be printed at a 1Hz rate for logging. The output stream can be stopped with a Ctrl-C.

Level: User, Admin and Supervisor

#### **4.4.19 get gnss**

This command displays the current settings for the GNSS receiver

Command Syntax:

*get gnss ↵*

Level: User, Admin and Supervisor

#### **4.4.20 set gnss**

This command allows change to GNSS receiver settings.

Command Syntax:

*set gnss [constellation <c>] [elev <E>] [level <L>] [pdop <P>]  
[adelay <d>] [pos <p>]  
[antenna [on|off]]  
[restart <r>] ↵*

Where:

- |                   |  |
|-------------------|--|
| constellation <c> | Set the current constellation in use by the receiver to <c>, where <c> can be any valid combination of the following, separated by ' ':<br>gps : GPS constellation<br>glo : GLONASS constellation<br>bds : Beidou constellation<br>gal : Galileo constellation<br>qzs : QZSS constellation (forces GPS on) |
| elev <E>          | Set the satellite elevation mask (degrees) to <E>  |
| level <L>         | Set the acquisition/tracking signal level (dBHz) to <L>  |
| pdop <P>          | Set the PDOP mask level to <P>   |
| adelay <d>        | Set the antenna delay for the system. This affects all timing outputs from the system.   |

- `<d>` is in nanoseconds with a range of +/- 50000000 (50ms).
- `pos <p>` Set the receiver position or mode. Where `<p>` is of the format:  
`{<lat> <lon> <ht>} | auto | survey`  
 Where:  
`<lat>` and `<lon>` are in degrees and `<ht>` in meters (HAE).  
*Note that the position will be validated by the receiver for accuracy and, if it is too far out of range (thereby making the timing of the unit inaccurate) the position will be recomputed.*  
 'auto' sets the unit to not force a user entered position on startup. If the unit has a stored position then it will be used on startup, with the same validation criteria as used for a user entered position.  
 'survey' forces the unit to recompute a surveyed position. The surveyed position will then be used by the system on the next startup (to speed startup). This also forces 'auto' mode.
- `length <s>` Set the survey length. This is the number of position fixes that will be averaged. Only fixes that match other criteria (PDOP) will be used in the average. Acceptable range is from 60 (1 minute) to 259200 (3 days).
- `antenna [on|off]` Enable/disable the power to the antenna. If power is turned off then no status will be generated, and no antenna alarm conditions are available (they will be cleared).
- `restart <r>` Restart the receiver using one of the following restart types:  
     cold - data transmitted by satellites cleared then receiver is restarted.  
     Warm - retain satellite data, just restart receiver.

**NOTE – The restart option is available at supervisor level access.**

Example:

```
set gnss constellation gps|bds elev 5 adelay 5000
set gnss pdop 4 elev 10
```

Level: Admin and Supervisor

#### 4.4.21 view gnss

The `view gnss` command displays the current GNSS receiver tracking information.

Command Syntax:

```
view gnss ↵
```

If the option “stream” is given, then the measurements will be printed at a 1Hz rate for logging. The output stream can be stopped with a Ctrl-C.

Examples include:

```
view gnss ↵
view gnss stream ↵
```

Level: User, Admin and Supervisor

#### 4.4.22 help

The help command allows to get an overview of the GM200 (help intro), to get a list of the available commands (help commands), or to get a description of an individual command.

Help is available for common tasks (HOWTOs), and to answer event or condition related questions (WHATIFs).

Examples include:

*help intro*

*help commands*

*help set*

#### 4.4.23 howto

The CLI command *howto* provides a list of frequently used task and help on the related CLI options.

Command Syntax:

*help howto <n> ↵*

Where <n> is number 1 to 12.

1. How to get current Alarm status
2. How to set alarm number 2 with setTime as 2 and clearTime as 1?
3. How to enable Ethernet port 0/1
4. How to set IP address of 192.168.0.9 on Ethernet 0 port?
5. How to set BNC output of even?
6. How to set periodic output of period 2 and value 1?
7. How to set serial port baud rate to 19200bps?
8. How to add a new user called trimble1 with an access level of user?
9. How to delete an existing user Trimble?
10. How to change user password?
11. How to restore factory default settings?
12. How to reboot the system?

Examples include:

*help howto 4*

Level: User, Admin and Supervisor

#### 4.4.24 *get input*

The *get input* command generates a list of the frequency control input candidates.

Command Syntax:

```
get input <input type>↵
```

Where:

*<input type>* is from the list:

GNSS                    Use the GNSS receiver as source for time/frequency

If no parameters are passed the candidacy of all inputs are returned.

Examples include:

```
get input ↵
```

```
get input gnss ↵
```

Level: User, Admin and Supervisor

#### 4.4.25 *set input*

The *set input* command allows setting of the frequency control reference input candidates. You can avoid the unit going into holdover due to the loss of an input as it will be able to select from other input candidates in the event of the loss of an input.

Command Syntax:

```
set input [ <input type> ] {enable/disable}↵
```

Where:

*<input type>* is from the list:

GNSS\*                  Use the GNSS receiver as source for time/frequency

enable                  Enable the *<input type>*(s) as valid inputs. If no *<input type>* is given then the entries marked with '\*' above are enabled

disable                  Disable the *<input type>*(s) as usable inputs. If no *<input type>* is given then all inputs are disabled

The order of preference of the input selection is:

GNSS

Examples include:

```
set input GNSS enable ↵
```

```
set input enable ↵
```

The last example would enable all '\*' inputs as valid candidates.

Level: Admin and Supervisor

#### 4.4.26 view input

The *view input* command displays the statistics on the current input sources for frequency control.

Command Syntax:

```
view input [<ref type> [stream]] ↵
```

Options:

<ref type> can be one of:

[GNSS]

stream view continuous output from system. Only valid with a <ref type> selection. You can terminate the stream with: ctrl-C, 'q', 'Q', 'x' or 'X'.

If no <ref type> is passed then statistics for all currently enabled input sources is returned

Examples include:

```
view input ↵
```

```
view input gnss ↵
```

Level: User, Admin and Supervisor

#### 4.4.27 view logs

The *view logs* command displays the system messages. Each message displayed will include the data and time of the event as well as short description of the event itself.

Command Syntax:

```
view logs [<type>] [<level>] [head | tail] [all | -n X]
         [clear] ↵
```

Options:

<type> can be one of:

alarm	View only alarm log information
freq	View only Time/Frequency control log information
gnss	View only GNSS log information
cfg	View only configuration log information
cli	View only CLI log information
comm	View only communication type log information

<level> can be combination of:

error	View only error conditions in the log information.
warning	View only warning conditions, these are events that may be significant, but are generated by the system in normal operation.
notice	View only notice log information, these are normal but, significant conditions.
info	View only informational log information. These are normal but insignificant conditions.

head View the beginning of the log (earliest) (default is tail)

tail View the end of the log (latest)

all View entire log

-n X View only a count of 'X' from the log. Default is 20

clear Clear the system message log. This should be used sparingly as any traceability of cause/effect will be lost.

**Note:** *The system event messages are normally presented with the newest event first. If 'head' is specified then the oldest event is presented first.*

Examples include:

```
view logs -n 10 gnss head ↵
```

```
view logs all ↵
```

```
view logs clear ↵
```

Level: Admin and Supervisor

#### 4.4.28 get network

This command displays the current network interface status.

Command Syntax:

```
get network [interface] ↵
```

Where:

<Interface> (optional) is a network interface such as eth0, eth1 or eth2.  
If no interface is specified all are displayed.

Level: User, Admin and Supervisor

#### 4.4.29 set network

The *set network* command configures the network connection. This is a multi-option command.

Command Syntax:

```
set network [<iface>] [default] | [disable] | [<ip>] [<vlan>] ↵
```

**NOTE – The default must be used by itself and restores the network settings to their default values.**

Where:

<iface>	Network interface definition, where <iface> is one of:
eth0	Network interface Ethernet 0 (timing port)
eth1	Network interface Ethernet 1 (timing port)
eth2	Network interface Ethernet 2 (management port)

The iface may indicate a VLAN with the form:  
<eth0|eth1|eth2|>[.vlanId]

default	Restore network setting(s) to default value. This must be used with no other setting options.
disable	Completely disable this interface. This stops all activity from this interface. The interface is enabled by commanding 'enable' or by setting any DHCP or IPAddr for this interface.
enable	Bring a previously disabled interface to the active, or 'up' condition. Note that, if the interface does not have valid parameters set the interface may still not be usable. Enabling the interface can also be done by setting any DHCP or IPAddr for this interface.
<ip>	IP configuration information for this port. This has the following format: [dhcp   dhcp6   slaac] [addr <i>][mask <m>][gateway <g>][bcast <bm>] [addr6 <i6>]

Where:

dhcp	Sets to port to utilize Dynamic IP Address (Dynamic Host Configuration Protocol) for IPv4
dhcp6	Sets the port to utilized Dynamic IP Address (Dynamic Host Configuration Protocol) for IPv6. Note that you can have DHCP for IPv6 and static addresses for IPv4 (and vice-

- verse).
- slaac Sets the port to utilize the SLAAC (Stateless Address Auto-configuration) IPv6 address assignment.
  - <i> IP address of the unit, in xxx.xxx.xxx.xxx format
  - <m> Netmask for the unit, in xxx.xxx.xxx.xxx format
  - <g> Gateway/Router IP address for the unit, in xxx.xxx.xxx.xxx format
  - <bm> Broadcast mask for the unit, in xxx.xxx.xx.xxx format
  - <i6> IPv6 address for the unit. This must be in CIDR format which is the IPv6 address with a /mask value. If no /mask value is given the default mask size of 128-bits is assumed.
- <vlan> VLAN configuration parameters, valid only for non-management, non-vlan, ports, of the format:  
[vlan <vl>] [prio <p>].
- Where:
- <vl> Comma separated list of VLAN IDs to use as the current VLAN list. Note that this list replaces any other VLAN list that is currently in use. To disable VLAN on the port use the special ID of '-1'. This will delete all VLANs associated with this port. Value VLAN ID numbers are from 0-4094, with the addition of '-1' to disable VLAN entirely.
  - prio Set the priority byte for the VLAN to <p>, where <p> can be a number between 0 (lowest) to 7 (highest). This priority applies to all VLAN connections.

Examples include:

```
set network eth0 addr 192.168.0.9 mask 255.255.255.0 bcast 192.168.0.255
set network eth0 gateway 192.168.0.1
set network eth0 addr6 dead:beef::/24
set network eth1 dhcp vlan 100,200,300
set network eth1 vlan 200,300
set network eth1.200 addr 192.168.1.12 mask 255.255.255.0 bcast 192.168.0.255
set network eth0 vlan -1
```

Level: Admin and Supervisor

#### 4.4.30 view network

The *view network* command allows user to view current network interfaces stats.

Command Syntax:

```
view network <eth0|eth1|eth2> ↵
```

If no interface name is given, then statistics for all interfaces are presented. Examples

include:

```
view network ↵
view network eth1 ↵
```

Level: User, Admin and Supervisor

#### 4.4.31 get ntp

The `get ntp` command allows user to display current NTP broadcast setting for eth0 or eth1 ports. If no option given then all ports are returned. If you desire to view the current NTP statistics then use 'view ntp'.

If NTP broadcast is enabled then this command will return the broadcast settings, otherwise it will return 'broadcast disabled'.

Command syntax:

```
get ntp <eth0 | eth1 | iff> ↵
```

Where:

<iff> If encryption is enabled then this will present the IFF certificate information to provide to the clients. This is ONLY available if you are connected through a secure connection (SSH or local serial port). The information presented should be copied from the terminal into a file, named to the filename indicated in the information and then that file distributed, securely, to your clients. (This option is available only to supervisor level user)

Examples include

```
get ntp ↵
```

```
get ntp eth0 ↵
```

```
get ntp iff ↵
```

Level: User, Admin and Supervisor

#### 4.4.32 set ntp

The `set ntp` command configures the NTP broadcast information.

Command syntax:

```
set ntp [<eth0|eth1>] <options> ↵
```

The port information (eth0|eth1) must be supplied for options marked with an '\*'. They are optional on other commands, unless noted.

where <options>:-

disable	Disable NTP for the given port. This stops all NTP traffic for the port.
enable	Enable NTP for the given port. This starts NTP traffic for the port.

default	Restore default settings for the port. If supplied. If no port supplied then all ports are affected. This option may not be used with any other options.
*bcast <ip> off	Set broadcasting on/off for the port. If an <ip> address is given, it must be in the same domain as the domain of the port. This is to keep from broadcasting to the whole internet.
*interval <n>	Set the broadcast time interval to <n> where <n> is the broadcast time interval, in seconds to the power of two. For example, a minpoll value of 4 sets the broadcast time interval to 2 <sup>4</sup> or 16 seconds. Allowable values are from 4 (16 sec) to 17 (36.4 hours).
*ttl <t>	Set the time-to-live hops to <t>. Allowable values are from 1 to 7, or '-'. Note that a value of '-' sets the default maximum hop value allowed.
encrypt on off	Set the encryption of the NTP messages on/off.
host (hn)	Set the host name for the encryption certificate to <hn>. Only the characters '-', '_', 0-9, A-Z, and a-z are valid within the host name. The max size of the host name is 32 characters.
group <gn>	Set the group name for the encryption certificate to <gn>. Only the characters '-', '_', 0-9, A-Z, and a-z are valid within the group name. The max size of the group name is 32 characters
peer <pl>	Set the peer list to <pl>. <pl> may be a comma separated list of up to 4 peers to use. This list must contain no spaces and may be made up of a mixture of IPv4, IPv6 or valid hostnames. The other allowable <pl> option is '-', which disables peering (regardless of where it is in the list).
iff	This will renew the IFF certificate for NTP certification. This should be done approximately every 30 days to keep the certificate valid

Examples include:

```
set ntp eth1 bcast 10.1.140.225 interval 4 ↵
set ntp eth0 encrypt on host Trimble group MyGroup1 ↵
set ntp peer 192.168.0.80,10.1.140.80,time.nist.gov ↵
```

**Note - Any changes to NTP configurations requires the shutting down and restarting of NTP.**

**Note - IP address changes (as through DHCP) are not service disrupting to NTP.**

Level: Admin and Supervisor

#### 4.4.33 view ntp

The *view ntp* command allows user to display current NTP stats.

Command Syntax:

```
view ntp [stream] ↵
```

If the option “stream” is given, then the measurements will be printed at a 1Hz rate for logging. The output stream can be stopped with: ctrl-C, 'q', 'Q', 'x' or 'X'.

Examples include:

*view ntp stream ↵*

Level: User, Admin and Supervisor

#### **4.4.34 get output**

The *get output* command returns the current output settings for the system. If no options given, then the all output settings are returned.

Command Syntax:

*get output [<sel>] ↵*

Where <sel> may be:

bnc Get output settings for BNC output only

Examples include:

*get output bnc*

*get output*

Level: Admin and Supervisor

#### **4.4.35 set output**

The *set output* command allows setting of the output signal(s) for the system. If no output signal selection is given, then all outputs are changed.

If an output is not valid for the given signal, then that output is turned off.

The 'invert' (or 'falling') modifier inverts the active state of the output. This affects all levels for the given signal. That means that if the output is set 'high' for instance the 'invert' option changes the output to 'low'. The "falling" modifier is an edge trigger.

*Note that this is a modifier and cannot be used alone.*

The 'width' option sets the pulse width for both BNC and digital.

*Note that the 'periodic' output has its own width, set with the 'set periodic' command.*

The 'delay' option allows setting of a delay for the timing. This is used to compensate for cable and other delays. The <d> value is in nanoseconds.

Command Syntax:

*set output [<sel>]  
    <off|low|high|pps|even|10mhz|periodic> [invert|falling]  
    [width <w>] [delay <d>] ↵*

Where <sel> may be:

bnc Change settings for the BNC output signal.

Examples include:

```
set output bnc even↵
```

```
set output pps↵
```

Level: Admin and Supervisor

#### 4.4.36 *get periodic*

The *get periodic* command returns the current settings for the periodic output selection

Command Syntax:

```
get periodic↵
```

Level: User, Admin and Supervisor

#### 4.4.37 *set periodic*

The *set periodic* command allows setting of the periodic output.

Command Syntax:

```
set periodic [period <p>] [value <v>] [width <w>]
```

Where:

period <p> set the period for the output in seconds.

The smallest value is '2' (otherwise use pps). The largest value is 100000.

value <v> set the value for the second count to generate the pulse. This can go from 0 to <p> - 1.

width <w> set the pulse width for the periodic output in ns. Range is 100ns to 5E8 (1/2 second)

Examples include:

```
set periodic period 2 value 1↵
```

*The above would set a pulse output every 2 seconds, on the odd pulse.*

Level: Admin and Supervisor

#### 4.4.38 *ping*

The *ping* command allows validation of a route to another IP system on the network.

Command Syntax:

```
ping [eth0|eth1|eth2] <ipaddr>↵
```

Where:

<eth0> Network interface Ethernet 0

<eth1> Network interface Ethernet 1

<eth2> Network interface Ethernet 2

<ipaddr> Valid IPv4 address of the unit, in xxx.xxx.xxx.xxx format

*NOTE – If no port is given then the management port is assumed. The ports may be on separate physical networks, make sure the network interface corresponding to the device pinged is used.*

Level: User, Admin and Supervisor

#### **4.4.39 ping6**

The *ping6* command allows validation of a route to another IP system on the network.

Command Syntax:

```
ping6 [eth0|eth1|eth2] <ipaddr>↵
```

Where:

<eth0>	Network interface Ethernet 0
<eth1>	Network interface Ethernet 1
<eth2>	Network interface Ethernet 2
<ipaddr>	IPv6 address of the unit without any mask information

*NOTE – If no port is given then the management port is assumed. The ports may be on separate physical networks, make sure the network interface corresponding to the device pinged is used.*

Level: User, Admin and Supervisor

#### **4.4.40 view pos**

The *view pos* displays the current receiver position information. Command

Syntax:

```
view pos [stream]↵
```

Where:

<stream>	View a continuous stream of frequency control data
----------	--

Level: User, Admin and Supervisor

#### **4.4.41 view prodconf**

The *view prodconf* displays the production configuration information that was set by Trimble manufacturing during production.

Command Syntax:

```
view prodconf↵
```

Examples include:

```
view prodconf↵
```

Returns:

- Serial number
- Build date

Premium bits (*this option is available only to supervisor level user*)

Product ID

Hardware ID

Extended S/N

Level: User, Admin and Supervisor

#### **4.4.45 quit**

The *quit* command is use to end a CLI session. You can use either "quit" or "q" to end the session.

Command Syntax:

```
quit ↵
```

```
q ↵
```

Level: User, Admin and Supervisor

#### **4.4.46 view realtime**

Show/Change the current level of the messages display. This command allows changing of the realtime event message level for this session (not stored).

Default is level 1 (alarms only).

Command Syntax:

```
view realtime [<level>]↵
```

Where the <level> value means:

- 0 No events will be shown in realtime
- 1 Only alarm events will be shown in realtime (default)
- 2 All events will be shown in realtime

Examples include:

```
view realtime↵
```

```
view realtime 2↵
```

#### **4.4.47 help set**

The *help set* command allow user to set system parameters. Command

Syntax:

```
help set <alarm /comm /gnss /input /network /ntp/output / user> ↵
```

Level: Admin and Supervisor

#### **4.4.48 get snmp**

The *get snmp* command returns the current SNMP settings. SNMP needs to be configured for trap generation and to set the SNMP community strings.

Command Syntax:

*get snmp* ↵

Level: User, Admin and Supervisor

#### **4.4.49 set snmp**

The *set snmp* command allows configuring the SNMP trap information.

Command Syntax:

*set snmp <options>* ↵

Where *<options>* are:

enable	enable SNMP with the current options
disable	disable SNMP operation
version <v>	set the SNMP version type, only 'v2c' is currently usable
host <ip>	set the IP address of the unit to receive the traps
port <p>	set the port number SNMP
community <c>	set the community string ID for SNMP
readonly <r>	Set the read-only community string ID to <r>.
readwrite <w>	Set the read-write community string ID to <w>.
gentraps	Test generation of all alarm traps (set & clear) that can be generated by the system. No functionality is affected, only the traps are generated. This command cannot be used with any other commands.

Examples include:

```
set snmp port 162 host 192.168.1.4 ↵  
set snmp readonly "public" ↵  
set snmp gentraps ↵
```

Level: Admin and Supervisor

#### **4.4.50 view summary**

The *view summary* command displays a summary of the frequency control, GNSS tracking status and receiver positioning information.

Command Syntax:

*view summary* ↵

Level: User, Admin and Supervisor

#### **4.4.51 view stream**

The *view stream* command displays a continuous stream of system performance data. This includes frequency control data as well as GNSS tracking information.

Command Syntax:

```
view stream ↵
```

Level: Supervisor

#### 4.4.52 get syslog

This command displays the current settings for the syslog server connection configuration. There are no options for this command.

Command Syntax:

```
get syslog ↵
```

Level: User, Admin and Supervisor

#### 4.4.53 set syslog

The *set syslog* command allows user to configure the syslog server connection. By default this connection is disabled..

Command Syntax:

```
set syslog [enable/disable] [addr <ip>] [port <port>] ↵
```

Where:

- |         |  |
|---------|--|
| enable  | Enable the sending of syslog messages to the syslog server. Note that until the address is configured with the address of a valid syslog server no messages will be sent, regardless of whether the service is enabled or not.   |
| disable | Disable the sending of syslog messages to the syslog server. This has no effect on any other settings.   |
| <ip>    | Valid IP address for the syslog server. This may be either an IPv4 type address, or an IPv6 type address. Only one address type at a time is supported. The corresponding 'source' information in the syslog message will be either the IPv4, or IPv6, address of the GM, depending on the format of this setting. |
| <port>  | Valid port for the syslog server. Setting of this value allows deviation from the syslog specification. The default port is 514.   |

Examples include:

```
set syslog enable addr 192.168.2.100↵
```

```
set syslog disable↵
```

```
set syslog port 4022↵
```

The last example would set the syslog port to a non-standard port for the protocol. This should be used only in controlled environments.

Level: Supervisor

#### 4.4.54 view temp

The *view temp* command displays the current system temperature in °C.

Command Syntax:

```
view temp ↵
```

Level: User, Admin and Supervisor

#### 4.4.55 get time

This command retrieves the current system UTC time.

Command Syntax:

```
get time [full] ↵
```

If the option 'full', is given this returns both the date and time.

```
get time full ↵
```

Use the *get time full* command to retrieve the current system date and UTC time. The format of the output is:

```
B d Y <hh:mm:ss>
```

Where:

B	is the full month string
d	is the day of month (00-31)
Y	is the full year, including century
hh:mm:ss	is the current UTC hour, minute and second

Level: User, Admin and Supervisor

#### 4.4.56 view uptime

The *view uptime* command displays the current 'up-time' of the system, which is how long the timing system has been operational.

This command takes no options.

Command Syntax:

```
view uptime ↵
```

Level: User, Admin and Supervisor

#### 4.4.57 get user

This command retrieves the current user names, access levels and email addresses for users that are at, or below your, access level.

Command Syntax:

*get user* ↵

Level: User, Admin and Supervisor

#### **4.4.58 set user**

The *set user* command allows changing user configuration.

Command Syntax:

*set user* <adduser / deluser / level / passwd | email | logout>↵

Where:

- |                                |   |
|--------------------------------|---|
| <b>adduser</b> <uname> <level> | Add a new user, named <uname>, with access level <level>. <uname> can contain only letters and numbers, no spaces or punctuation is allowed. If the user already exists, no action is taken.<br><level> can be one of: <ul style="list-style-type: none"><li>user : this level can only view status and configuration, no changes to configuration.</li><li>admin : all functions of 'user' with added ability to change most configuration settings.</li><li>super : all functions of 'admin' with added ability to edit the user table.</li></ul> |
| <b>deluser</b> <uname>         | Delete a user. You cannot delete yourself. If the user does not exist, an error is returned.  |
| <b>level</b> <uname> <level>   | Change the access level for a user. See 'adduser' for descriptions of levels  |
| <b>passwd</b>                  | Change the password. If you are changing your own password then you will be queried for your old password first. Only supervisors can change someone else's password.<br>This can accept a username and, if one is given, you can change the password of the user. You will not be prompted for their old password. Note that a blank password is not allowed.  |
| <b>email</b> [<uname>] <email> | Change the email address for user. You will be queried for your password to allow changes. If no <uname> is given then the current user is assumed.<br>Only supervisors can use the optional '<uname>' parameter.<br>This can accept a username and, if one given, you can change the email address of the user.  |
| <b>logout</b> [options]        | Log out the user with the given option selections.<br>Please see 'help set user logout' for information about the options.  |

Level: Supervisor

#### 4.4.59 set user logout

The *set user logout* command allows the Thunderbolt TS200 GM200 to log users out of the system. Users may log in through various methods on the system, this command allows logging out users with varying selection options.

Command Syntax:

```
set user logout [name (n)] [sid(s)] [service(svc)]↵
```

Where:

- <n>            The name of the user. Logged in users with the name <n> will be logged out. This will affect all services and sessions.
- <s>            The session ID to log out. Users logged in with this session ID will be logged out. This limits the logout to only a single entry since session ID's are unique. The session ID can be found using the 'view user' command.
- <svc>         The service name to log out. All users connected to this service type will be logged out. This can affect more than one logged in user; for instance if a user has multiple logins from the same IP address this will log out all of the sessions. Note that users with the same name logged in on a different service will not be affected.

Examples:

```
set user logout sid 4  
set user logout service 10.1.140.111  
set user logout name trimble service 10.1.140.111
```

In the above examples, the first would log out a single user session.  
The second example logs out all users connected from a specific IP address.  
The third example will only log out a certain user, logged in from a specific IP address

Level: Supervisor

#### 4.4.60 view user

The *view user* command retrieves the list of currently logged-in user that are at, or below the current access level.

Command Syntax:

```
view user ↵
```

Level: User, Admin and Supervisor

#### 4.4.61 view version

The *view version* command displays the current versioning information for the product..

Command Syntax:

```
view version <hardware|gnss>↵
```

Where:

<hardware> View the hardware version of the Thunderbolt TS200  
<gnss> View only the GNSS version

Examples include:

```
view version↵
```

```
view version hardware↵
```

Level: User, Admin and Supervisor

#### **4.4.62.0 view**

The *view* command allows seeing both the current system status and system level operational information

Command Syntax:

```
help view <X>↵
```

Where <X> can be:

access	View access level for logged in user
alarm	View currently active alarms on the system
dlog	View system data logging information
freq	View current frequency control information
gnss	View current GNSS tracking status
input	View statistics for input sources
logs	View system message log data
network	View network statistics
ntp	View current NTP stats
realtime	Configure the messages shown on this port
pos	View current receiver position information
stream	View a continuous stream of frequency control data
summary	View the frequency, GNSS and position information with one option.
temp	View the current system temperature.
uptime	View the current 'up-time' of the system.
user	View the current logged-in users
version	View the version information for the unit.
prodconf	View the production configuration information

Examples include:

```
view
```

```
view gnss
```

```
view logs
```

```
view dlog
```

*NOTE – Some view options like logs, stream are visible to admin and/or supervisor levels.*

Level: User, Admin and Supervisor

#### **4.4.62.1 view gnss stream**

View the current GNSS receiver tracking information as a continuous streaming output. The streaming may be stopped by pressing one of the following keys on your terminal:

ctrl-C, 'q', 'Q', 'x' or 'X'.

This command takes no options.

#### **4.4.62.2 view dlog**

Use the view dlog command to display collected data from the datalogger. Usage:

*view dlog g*

*view dlog pos*

*view dlog freq*

#### **4.4.63 whatif**

The *whatif* command gives some information about scenarios you may encounter and how to recover from those. Command Syntax:

*help whatif ↵*

##### 1) You have an FPGA-Load-Bad alarm

This is an indication of an out-of-date FPGA load. This can be remedied by a supervisor level person applying a hardware update load to the system. The supervisor can refer to the '*config firmware*' section for more information.

Level: User, Admin and Supervisor

## **4.5 List of “How to” help topics**

The *howto* command provide a list of frequently used task and help on the related CLI options.

The list of frequently used tasks is the following

1. How to get current Alarm status
2. How to set alarm of level major, alarm number 2 with setTime as 2 and clearTime as 1?
3. How to enable Ethernet port 0/1
4. How to set ip address of 192.168.0.9 on ethernet 0 port?
5. How to set bnc output of even?
6. How to set periodic output of period 2 and value 1?
7. How to set serial port baud rate to 19200bps?
8. How to add a new user called trimble1 with an access level of user?
9. How to delete an existing user trimble?
10. How to change user password?
11. How to restore factory default settings?
12. How to reboot the system?

Command format:

```
help howto <n>
```

Where: <n> is one of the above topic numbers.

For example,

```
>  
> help howto 1  
How to get current Alarm status:  
  
get alarm  
  
>
```

#### **4.5.1 How to get current Alarm status?**

```
get alarm
```

#### **4.5.2 How to set alarm of level major, alarm number 2 with setTime as 2 and clearTime as 1?**

*NOTE: This is only possible from an admin (or higher) access level*

```
set alarm 2 maj 2 1
```

#### **4.5.3 How to disable Ethernet port 0/1?**

*NOTE: This is only possible from an admin (or higher) access level*

```
set network eth0 disable  
set network eth1 disable
```

#### **4.5.4 How to set ip address of 192.168.0.9, and also set a netmask and a gateway address on ethernet 0 port?**

*NOTE: This is only possible from an admin (or higher) access level*

```
set network eth0 addr 192.168.0.9 netmask 255.255.255.0 gateway 192.168.0.1
```

#### **4.5.5 How to set bnc output of even?**

*NOTE: This is only possible from an admin (or higher) access level*

```
set output bnc even
```

#### **4.5.6 How to set periodic output of period 2 and value 1?**

*NOTE: This is only possible from an admin (or higher) access level*

```
set periodic period 2 value 1
```

#### **4.5.7 How to set serial port baud rate to 19200bps?**

*NOTE: This is only possible from an admin (or higher) access level*

```
set comm baud 19200
```

#### **4.5.8 How to add a new user called trimble1 with an access level of user?**

*NOTE: This is only possible from a supervisor access level*

```
set user adduser trimble1 user
```

#### **4.5.9 How to delete an existing user trimble?**

*NOTE: This is only possible from a supervisor access level*

```
set user deluser trimble
```

#### **4.5.10 How to change user password?**

```
set user passwd <new_passwd>
```

#### **4.5.11 How to restore factory default settings?**

*NOTE: This is only available from an admin (or higher) access level*

```
config load factory
```

#### **4.5.12 How to reboot the system?**

*NOTE: This is only available from a supervisor access level*

```
config system reboot
```

## 4.6 List of “What if” help topics

This section gives some information about some scenarios, you may encounter and how to recover from those.

### *4.6.1 What if you have an FPGA-Load-Bad alarm*

This is an indication of an out-of-date FPGA load. A supervisor level person applying a hardware update load to the system can remedy this. The supervisor can refer to the '**config firmware**' section for more information.



## Chapter 5: Web Interface

In this chapter:

[Configuration Pages](#)

[Status Pages](#)

This chapter provides explanation on the web interface of Thunderbolt® NTP Time Server Clock TS200

## 5.1 Home Page

Launch a web browser and open a connection to Thunderbolt® NTP Time Server Clock TS200 by entering the URL that specifies the IP address.

<http://192.168.2.250>

Web access is permitted only through Ethernet port-2. The default IP Address for Ethernet port-2 is 192.168.2.250.

**NOTE** – Trimble recommends using Google Chrome browser for better rendering of Thunderbolt® NTP Time Server Clock TS200 web pages.

Entering the IP address will launch the main or home page.

System Status	
<b>Alarm Status</b> Major	<b>Input Status</b> GNSS: Lock
<b>Configuration Status</b> Configuration is saved	<b>Product ID</b> 111224-50
<b>Management Port Status</b> Connected 100MB	<b>Software Version</b> 20180204-0.0.9.0
<b>Ethernet Port 0 Status</b> Not Connected	<b>Time (UTC)</b> 02/28/2018 07:12
<b>Ethernet Port 1 Status</b> Not Connected	<b>Up Time</b> 07:41

The main page will display a brief status of the Thunderbolt® TS200. The components of this page are:

- **Alarm Status:** Shows the list of active alarms
- **Input Status** Shows the input reference of GM200
- **Configuration Status** Shows the status of the current configuration saved
- **Product ID** Shows the Trimble part number of GM200
- **Management Port Status** Shows the status of the Management Ethernet port
- **Software Version** Displays the current firmware version on the unit
- **Time (UTC)** Displays the time in UTC format
- **Up Time** Displays how long the unit is powered on.
- **Ethernet Port 0 Status** Displays the status of NTP Ethernet Port 0
- **Ethernet Port 1 Status** Displays the status of NTP Ethernet Port 1

Log in to the Thunderbolt® TS200 to view or change system parameters. The **login** option is available at the top left of main landing page.

### Refresh Rate


The main page is refreshed at a rate of 1 second.

## 5.2 Login Page

Use the Thunderbolt® TS200 Login page to view system status. The login page requires a valid username and password.

The default users are:

- **Username:** trimble
- **Password:** trimble
- **Access level:** *User*
  
- **Username:** trimbleadmin
- **Password:** trimbleadmin
- **Access level:** *Admin*
  
- **Username:** trimblesuper
- **Password:** trimblesuper
- **Access level:** *Super*



The screenshot shows the login interface for the Thunderbolt NTP TS200. At the top right, a dark blue banner contains the text "Welcome. Login for more detailed views." The main header features the Trimble logo with the tagline "Transforming the way the world works" and the product name "Thunderbolt NTP TS200" in large blue font. Below the header is a "System Access" section with a light blue background. It contains two input fields: "Username" and "Password", both with green borders. Below these fields is a white button with a blue border labeled "Authorize". On the left side of the page, there is a small image of the Thunderbolt NTP TS200 hardware device with its various ports and status indicators.

## 5.3 System Page

After entering the valid credentials, the Thunderbolt® TS200 launches the **System Page**. The system page is organized in two frames – the navigation and content.

The start page gives general status information of the Thunderbolt® NTP Time Server Clock TS200. By using the navigation menu on the left side of the screen, user can view a number of configuration pages which are described in following pages.

## 5.4 System Status

### *Alarms and Events - Alarms*

The page shows currently active alarm condition on the system.

The screenshot shows the Thunderbolt NTP TS200 web interface. At the top, there is a dark blue header with a 'Logout' button, a 'Disable auto-logout' checkbox, and a welcome message: 'Welcome *trimblesuper*. You have *super* access rights.' Below the header is the Trimble logo and the title 'Thunderbolt NTP TS200'. The main content area is titled 'Alarm Status and Event Log' and has two tabs: 'Alarms' (selected) and 'Event Log'. Under the 'Alarms' tab, there is a section titled 'List of Active Alarms' containing a table:

Alarm #	Alarm Description	Alarm Level
20	Eth-Port0-Down	Major
21	Eth-Port1-Down	Major

On the left side of the interface, there is a navigation menu with the following items: 'SYSTEM STATUS' (highlighted), 'Alarms and Events', 'System Info', 'Timing', 'GNSS', 'Network', 'INTERFACE MANAGEMENT', 'SYNCHRONIZATION MANAGEMENT', 'SECURITY MANAGEMENT', and 'SYSTEM MANAGEMENT'.

The Alarm Description window provides the details of each alarm and the alarm level

- **Alarm #:** Alarm code
- **Alarm Description:** Description of the alarm condition
- **Alarm Level:** Severity of alarm condition, can be notification only, minor, major or critical

The Event Log window provides the list of system messages and notifications.

- **Event Filter:** All, Alarms, Frequency, GNSS, Config Mods, Errors, Warnings, Notices, Information
- **Number of Events:** All, 10, 25, 50, 100
- **Download Log:** Select this button to download a text file with the message logs.
- **Clear Log:** Select this button to clear all message logs.

## System Info

The System Info status provides overall system information:

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button and a 'Disable auto-logout' checkbox. The user is logged in as 'trimblesuper' with 'super access rights'. The main header displays the Trimble logo and the product name 'Thunderbolt NTP TS200'. On the left, there is a sidebar with navigation options: 'SYSTEM STATUS' (highlighted), 'Alarms and Events', 'System Info', 'Timing', 'GNSS', 'Network', 'INTERFACE MANAGEMENT', 'SYNCHRONIZATION MANAGEMENT', 'SECURITY MANAGEMENT', and 'SYSTEM MANAGEMENT'. The main content area is titled 'System Information' and contains the following data:

Product ID 111224-50	Time (UTC) 02/28/2018 07:17
Hardware ID 111222-00	Up Time 07:45
Serial Number 1370000073	CPU Load Average 16 %
Extended S/N -	System Temperature 33.3 °C
Software Version 20180204-0.0.9.0	Memory - Active 87264 kB
Hardware Build Date 09/01/2017 15	Memory - Available 955712 kB

Below the data, there is a 'Download Support Info' button and a 'Realtime Graph View' section. The graph shows 'Average CPU Load (%)' over 27 time units. The CPU load starts at 17.00% and drops to 16.00% at time unit 7, remaining constant thereafter. A 'Close Graph' button is located to the right of the graph.

- **Product ID or Model:** The model number of the Thunderbolt® TS200.
- **Time (UTC)** Displays the time in UTC format
- **Hardware ID** Displays the hardware part number
- **Up Time** Displays how long the unit is powered on.
- **Serial Number:** The unique serial number of the Thunderbolt® TS200.
- **CPU Load Average:** A figure of merit for the operating system “load”
- **Extended S/N** Displays the extended serial number
- **System Temperature** Displays the Temperature of TS200
- **Software Version** Displays the current firmware version on the unit
- **Memory - Active** The amount of memory occupied by the system.
- **Hardware Build Date:** The date of firmware build
- **Memory - Available:** The amount of free memory remaining.
- **Download Support Info:** The support info can be downloaded as a file.
- **Realtime Graph View:** Displays the realtime graph of the following values:
  - CPU Load
  - Temperature
  - Mem – Active
  - Mem - Available


## Timing Status

This page provides the status information of System clock

The screenshot displays the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button and a 'Disable auto-logout' checkbox. The user is identified as 'Welcome trimblesuper. You have super access rights.' The main header features the Trimble logo and the product name 'Thunderbolt NTP TS200'. A left sidebar contains a 'SYSTEM STATUS' menu with options: Alarms and Events, System Info, Timing (highlighted), GNSS, and Network. Below this are sections for INTERFACE MANAGEMENT, SYNCHRONIZATION MANAGEMENT, SECURITY MANAGEMENT, and SYSTEM MANAGEMENT. The main content area is titled 'Timing Information' and includes tabs for 'Timing Status' and 'NTP Status'. It is divided into three sections: 'Input Status' (Sync Source: GNSS), 'Output Status' (Sync Out: PPS), and 'Sync Source Statistics'. The statistics section contains two tables. The first table shows GNSS with a Phase Offset of -0.263 ns, Mean of 0.260 ns, Sigma of 3.641 ns, and Freq Offset of -0.00777 ppb. The second table, 'Control Loop Status', shows a Lock state with a Holdover of 0 seconds, Phase Offset of -0.927ns, Freq Offset of -3.06285e-07, and Delta Freq of 3.663e-12. Below these tables is a 'Realtime Graph View' for 'Phase Offset' with a 'Close Graph' button. The graph shows a blue line representing the 'Control Loop Output' over 18 time units, with values ranging from -4.5 to 1.0.

- **Input Status**
  - **Sync Source:** Indicates the current sync source
- **Output Status**
  - **BNC Output:** Indicates the current configuration of BNC connector.
- **Sync Source Statistics**
  - **Sync Source:** Distinguishes the name of the Sync Source
  - **Phase Offset:** TS200 output PPS with reference to the sync source
  - **Frequency Offset:** The absolute frequency offset of the internal OCXO with reference to sync source
  - **Mean:** The mean phase offset
  - **Sigma:** The standard deviation of phase offset

- **Control Loop Status:** Status of system control loop of the system.
  - **Phase Offset:** Control loop output with reference to the sync source
  - **Frequency Offset:** The frequency offset of control loop of TS200
  
  - **Holdover:** The estimated holdover time available



Logout  Disable auto-logout Welcome *trimblesuper*.  
You have *super* access rights.

**Trimble** Thunderbolt NTP TS200

Transforming the way the world works

**SYSTEM STATUS**

- Alarms and Events
- System Info
- Timing**
- GNSS
- Network

**INTERFACE MANAGEMENT**

**SYNCHRONIZATION MANAGEMENT**

**SECURITY MANAGEMENT**

**SYSTEM MANAGEMENT**

**Timing Information**

**Timing Status** | **NTP Status**

Ethernet Port 0 Ethernet Port 1

NTP Server Enabled NTP Server Enabled

**NTP Statistics**

Description	Value
Status	0414
Stratum	1
Precision	+3.81 us
Offset	+62.44 ms
Frequency	+0 ppt
Jitter	+22.07 ms

- **Ethernet Port:** Identifies the Ethernet port – Eth0 or Eth1
- **NTP Status:** Show the status of port connection
- **NTP Time Server Statistics:** Shows the statistics of various server parameters

## GNSS Receiver Status

The page displays the status of GNSS receiver:

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button, a 'Disable auto-logout' checkbox, and a welcome message: 'Welcome trimblesuper. You have super access rights.' Below the navigation bar is the Trimble logo and the title 'Thunderbolt NTP TS200'. The main content area is titled 'GNSS Receiver Information' and contains two tabs: 'GNSS Receiver' (selected) and 'Satellite Data'. The 'GNSS Receiver' tab displays a table of receiver status information:

<u>Receiver Status</u>	<u>Position Info</u>	<u>Receiver Info</u>	<u>Antenna Info</u>
<b>GNSS Quality</b> 12 Very Good SVs	<b>Survey Length</b> 2000 secs	<b>GNSS Almanac</b> Good	<b>Antenna Delay</b> 0 ns
<b>Receiver Operation</b> Normal	<b>Latitude</b> N 19° 27.54540'	<b>Constellations</b> GPS GLO	
<b>Receiver Mode</b> Overdet Clock (Time)	<b>Longitude</b> W 99° 10.76855'	<b>UTC Offset</b> 18	
	<b>Altitude</b> 2247.38 m HAE	<b>Pending Leap</b> 0	

On the left side of the interface, there is a sidebar menu with the following sections: 'SYSTEM STATUS' (containing 'Alarms and Events', 'System Info', 'Timing', 'GNSS', and 'Network'), 'INTERFACE MANAGEMENT', and 'SYNCHRONIZATION MANAGEMENT'.

- **Latitude:** The latitude of the Thunderbolt TS200
- **Longitude:** The longitude of the Thunderbolt TS200
- **Altitude:** The altitude of the GNSS receiver
- **Receiver Status:** The current status of the receiver (*doing fixes, in clock mod*)
- **GNSS Almanac:** The status of GNSS Almanac
- **Constellations in use:** Current constellations that are being used
- **GNSS Quality Status:** A metric used to provide the user with a snapshot of the number of SVs with Very Good, Good, or Poor Signal Strength/Quality  
Quality is 'Very Good' if there are at least 4 SVs that have SNR > 35  
Quality is 'Good' if there are at least 4 SVs that have SNR > 20  
Quality is 'Poor' if there are not SVs that have SNR > 20
- **Antenna Delay:** Displays the compensation delay of antenna cable

Logout  Disable auto-logout Welcome *trimblesuper*.  
You have *super* access rights.

**Trimble**  
Transforming the way the world works

# Thunderbolt NTP TS200

## GNSS Receiver Information

**SYSTEM STATUS**

- Alarms and Events
- System Info
- Timing
- GNSS**
- Network

**INTERFACE MANAGEMENT**

**SYNCHRONIZATION MANAGEMENT**

GNSS Receiver

Satellite Data

SV	C/No	Az.	Elev.	SV	C/No	Az.	Elev.
2	41.0	43.0	31.0	85	31.0	82.0	22.0
25	47.0	283.0	48.0	76	42.0	242.0	19.0
12	52.0	212.0	56.0	86	44.0	20.0	38.0
5	47.0	30.0	61.0	72	44.0	171.0	58.0
13	43.0	136.0	27.0	71	46.0	52.0	56.0
29	46.0	330.0	29.0	65	0.0	196.0	13.0
20	48.0	235.0	53.0	77	0.0	299.0	11.0
15	47.0	174.0	24.0	87	0.0	323.0	12.0

- **SV:** Satellite Vehicle
- **C/No:** Carrier-to-Noise power ratio
- **Az:** Azimuth
- **Elev:** Elevation

## Network eth0

Network status for Ethernet Port 0:

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button and a 'Disable auto-logout' checkbox. The user is identified as 'trimblesuper' with 'super access rights'. The main title is 'Thunderbolt NTP TS200'. Below the title, there is a 'Network Information' section with tabs for 'Ethernet Port 0', 'Ethernet Port 1', 'Management Port', and 'Ethernet Statistics'. The 'Ethernet Port 0' tab is selected, showing the following information:

Ethernet Port 0			
<b>Connection Status</b> Not Connected	<b>MAC Address</b> 00:17:47:7F:FE:B2		
<b>IPv4 Assignments</b>			
<b>Address - Static</b> 1.1.1.251	<b>Subnet Mask</b> 255.255.255.0	<b>Gateway</b> 1.1.1.1	<b>Broadcast</b> 1.1.1.255
<b>IPv6 Assignments</b>			
<b>Address</b> fd6b:fd64:9e0c::128	<b>Scope</b> Global		
<b>Ethernet Assignments</b>			
VLAN IDs -			

- **IPv4 Address:** IP address of the port.
- **IPv4 Subnet Mask:** Subnet mask being used.
- **IPv4 Gateway:** Default gateway
- **IPv4 Broadcast:** Broadcast IP address
- **IPv6 Address/Mask:** IPv6 Address of the Ethernet interface with the subnet mask.
- **IP Assignment:** Either static or DHCP
- **Connection Status:** Status of Ethernet connection
- **MAC Address:** The MAC Address of the port

## Network eth1

Network status for Ethernet Port 1:

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button, a 'Disable auto-logout' checkbox, and a welcome message: 'Welcome trimblesuper. You have super access rights.' The main header displays the 'Trimble' logo and the product name 'Thunderbolt NTP TS200'. Below the header, there is a 'Network Information' section with a sidebar on the left containing menu items: 'SYSTEM STATUS' (with sub-items: Alarms and Events, System Info, Timing, GNSS, Network), 'INTERFACE MANAGEMENT', 'SYNCHRONIZATION MANAGEMENT', and 'SECURITY'. The main content area shows 'Ethernet Port 1' selected, with the following information:

Ethernet Port 0		Ethernet Port 1		Management Port		Ethernet Statistics	
<b>Connection Status</b> Not Connected		<b>MAC Address</b> 00:17:47:7F:FE:B3					
<b>IPv4 Assignments</b>							
<b>Address - Static</b> 4.4.4.251	<b>Subnet Mask</b> 255.255.255.0	<b>Gateway</b> -			<b>Broadcast</b> 4.4.4.255		
<b>IPv6 Assignments</b>							
<b>Address</b> fd6b:fd64:9e0c:1::/128				<b>Scope</b> Global			
<b>Ethernet Assignments</b>							
<b>VLAN IDs</b> -							

- **IPv4 Address:** IP address of the port.
- **IPv4 Subnet Mask:** Subnet mask being used.
- **IPv4 Gateway:** Default gateway
- **IPv4 Broadcast:** Broadcast IP address
- **IPv6 Address/Mask:** IPv6 Address of the Ethernet interface with the subnet mask.
- **IP Assignment:** Either static or DHCP
- **Connection Status:** Status of Ethernet connection
- **MAC Address:** The MAC Address of the port

## Network Management Port

Network status for Ethernet Management Port:

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button, a 'Disable auto-logout' checkbox, and a welcome message: 'Welcome trimblesuper. You have super access rights.' The main header displays the Trimble logo and the product name 'Thunderbolt NTP TS200'. Below the header, there is a 'Network Information' section. On the left, a sidebar menu includes 'SYSTEM STATUS' (highlighted), 'Alarms and Events', 'System Info', 'Timing', 'GNSS', 'Network', 'INTERFACE MANAGEMENT', and 'SYNCHRONIZATION'. The 'Network Information' section has four tabs: 'Ethernet Port 0', 'Ethernet Port 1', 'Management Port' (highlighted), and 'Ethernet Statistics'. The 'Management Port' tab shows the following information:

Connection Status		MAC Address	
Connected	100MB	00:17:47:7F:FE:B4	
<u>IPv4 Assignments</u>			
Address - Static	Subnet Mask	Gateway	Broadcast
37.13.44.151	255.255.255.0	37.13.44.1	37.13.44.255
<u>IPv6 Assignments</u>			
Address			Scope
fd6b:fd64:9e0c:2::/128			Global
fe80::217:47ff:fe7f:feb4/64			Link

- **IPv4 Address:** IP address of the port.
- **IPv4 Subnet Mask:** Subnet mask being used.
- **IPv4 Gateway:** Default gateway
- **IPv4 Broadcast:** Broadcast IP address
- **IPv6 Address/Mask:** IPv6 Address of the Ethernet interface with the subnet mask.
- **IP Assignment:** Either static or DHCP
- **Connection Status:** Status of Ethernet connection
- **MAC Address:** The MAC Address of the port

Logout  Disable auto-logout
Welcome *trimblesuper*.  
You have *super* access rights.



# Thunderbolt NTP TS200

SYSTEM STATUS

- Alarms and Events
- System Info
- Timing
- GNSS
- Network

INTERFACE MANAGEMENT

SYNCHRONIZATION MANAGEMENT

SECURITY MANAGEMENT

SYSTEM MANAGEMENT

Network Information +

Ethernet Port 0

Ethernet Port 1

Management Port

Ethernet Statistics


Statistic	Ethernet Port 0	Ethernet Port 1	Management Port
RX Bytes	N/A	N/A	14 MB
RX Packets	N/A	N/A	55980
RX Packets/Sec	N/A	N/A	2
RX Dropped	N/A	N/A	2
RX Errors	N/A	N/A	0
TX Bytes	N/A	N/A	32 MB
TX Packets	N/A	N/A	56660
TX Packets/Sec	N/A	N/A	3
TX Dropped	N/A	N/A	0
TX Errors	N/A	N/A	0
	<b>1-second</b>	<b>10-seconds avg</b>	
RX+TX Pkts/Sec	5	0	

## 5.5 Interface Management


### IP Assignment eth0

The screenshot displays the web management interface for a Thunderbolt NTP TS200 device. The top navigation bar includes a 'Logout' button, a 'Disable auto-logout' checkbox, and a welcome message for 'trimblesuper'. The main header shows the 'Trimble' logo and the device name 'Thunderbolt NTP TS200'. A left sidebar contains navigation menus for 'SYSTEM STATUS', 'INTERFACE MANAGEMENT' (with 'Ethernet' selected), 'SYNCHRONIZATION MANAGEMENT', and 'SECURITY MANAGEMENT'. The main content area is titled 'Ethernet Configuration' and shows settings for 'Ethernet Port 0'. It includes sections for 'Port Configuration' (set to 'Static'), 'Connection Status' (Not Connected), 'IPv4 Assignments' (Address: 1.1.1.251, Subnet Mask: 255.255.255.0, Gateway: 1.1.1.1, Broadcast: 1.1.1.255), and 'IPv6 Assignments' (IPv6 Mode: Static, Address: fd6b:fd64:9e0c::/128, Scope: Global). At the bottom, there are input fields for 'IPv4 Address' and 'IPv6 Address' to test ping, with 'Ping IPv4' and 'Ping IPv6' buttons.

- **Port Configuration:** Either DHCP, Static, Default or Disable this interface
- **IPv4 Address:** IPv4 address of the port
- **IPv4 Subnet Mask:** Subnet mask being used
- **IPv4 Gateway:** Default gateway IPv4 address
- **IPv4 Broadcast:** Either static or DHCP
- **IPv6 Address:** IPv6 Address of the Ethernet interface with the subnet mask.
- **Ping IPv4:** Enter IPv4 Address to test ping
- **Ping IPv6:** Enter IPv6 Address to test ping



- **Port Configuration:** Either DHCP, Static, Default or Disable this interface
- **IPv4 Address:** IPv4 address of the port
- **IPv4 Subnet Mask:** Subnet mask being used
- **IPv4 Gateway:** Default gateway IPv4 address
- **IPv4 Broadcast:** Either static or DHCP
- **IPv6 Address:** IPv6 Address of the Ethernet interface with the subnet mask.
- **Ping IPv4:** Enter IPv4 Address to test ping
- **Ping IPv6:** Enter IPv6 Address to test ping



- **Port Configuration:** Either DHCP, Static, Default or Disable this interface
- **IPv4 Address:** IPv4 address of the port
- **IPv4 Subnet Mask:** Subnet mask being used
- **IPv4 Gateway:** Default gateway IPv4 address
- **IPv4 Broadcast:** Either static or DHCP
- **IPv6 Address:** IPv6 Address of the Ethernet interface with the subnet mask.
- **Ping IPv4:** Enter IPv4 Address to test ping
- **Ping IPv6:** Enter IPv6 Address to test ping

Edit	Interface	Address	Mask	Gateway
<input type="radio"/>	eth0.20	3.1.30.100	255.0.0.0	3.1.30.1
<input type="radio"/>	eth0.30	4.1.42.100	255.0.0.0	4.1.42.1

- **VLAN IDs:** List of all VLAN IDs configured
- **Priority:** 0 to 7 where 7 is the highest priority

# VLAN eth1

Logout  Disable auto-logout Welcome *trimblesuper*.  
You have *super* access rights.

**Trimble**  
Transforming the way the world works

## Thunderbolt NTP TS200

### VLAN Configuration

Ethernet Port 0 | **Ethernet Port 1**

**VLAN Configuration**

**VLAN ID Assignments**

VID1	VID2	VID3	VID4	Priority
				0

To remove a VLAN ID, delete it's entry from the list.

Logout  Disable auto-logout Welcome *trimblesuper*.  
You have *super* access rights.

**Trimble**  
Transforming the way the world works

## Thunderbolt NTP TS200

### VLAN Configuration

Ethernet Port 0 | **Ethernet Port 1**

**VLAN Configuration**

**VLAN ID Assignments**

121	131	VID3	VID4	Priority
				0

To remove a VLAN ID, delete it's entry from the list.

**VLAN Interface Assignments**

Edit	Interface	Address	Mask	Gateway
<input type="radio"/>	eth1.121	21.134.199.220	255.255.255.248	21.134.199.221
<input type="radio"/>	eth1.131	5.122.135.124	255.0.0.0	5.122.135.255

Only one VLAN Interface may be assigned or modified per 'Set' command.

- **VLAN IDs:** List of all VLAN IDs configured
- **Priority:** 0 to 7 where 7 is the highest priority

## SNMP Configuration Basic


The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with 'Logout' and 'Disable auto-logout' options, and a welcome message for 'trimblesuper'. The main header displays the Trimble logo and the device name 'Thunderbolt NTP TS200'. The left sidebar contains a navigation menu with 'SYSTEM STATUS' and 'INTERFACE MANAGEMENT' (selected). Under 'INTERFACE MANAGEMENT', there are links for 'Ethernet', 'VLAN', 'SNMP', 'Syslog', and 'Serial Port'. The main content area is titled 'SNMP Configuration' and has two tabs: 'Basic' (selected) and 'SNMP v2c'. The 'SNMP Configuration' section has a dropdown menu set to 'SNMP V2c'. The 'Trap Community String' field contains 'public'. The 'SNMP/Trap Manager IP' field contains '37.13.44.113'. The 'SNMP/Trap Manager Port' field contains '162'. A 'Download MIBS' button is located to the right of the 'Trap Community String' field.

- **SNMP Configuration:** SNMP v2c or Disable
- **Trap Community String:** Community string id for SNMP
- **SNMP Manager IP:** IP address of SNMP manager that receives the TRAP
- **SNMP Manager Port:** Port number of SNMP manager
- **Download MIBs:** This option allows download of SNMP MIB

## SNMP Configuration v2c

The screenshot displays the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a "Logout" button and a "Disable auto-logout" checkbox. A welcome message reads: "Welcome *trimblesuper*. You have *super* access rights." The main header features the Trimble logo and the text "Transforming the way the world works" on the left, and "Thunderbolt NTP TS200" in large font on the right. Below the header, there is a "SNMP Configuration" section with two tabs: "Basic" and "SNMP v2c". The "SNMP v2c" tab is active, showing two text input fields: "Read Only Community" with the value "public" and "Read/Write Community" with the value "private". On the left side of the interface, there is a sidebar menu with "SYSTEM STATUS" and "INTERFACE MANAGEMENT" sections. Under "INTERFACE MANAGEMENT", the following options are listed: Ethernet, VLAN, **SNMP** (highlighted in orange), Syslog, and Serial Port.

- **Read Community:** Community string for read
- **Write Community:** Community string for write



- **Syslog Protocol:** Enable or Disable
- **Syslog Server:** IP Address of Syslog Server
- **Syslog Port:** Enter port

## Serial Port

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button and a 'Disable auto-logout' checkbox. On the right, a welcome message reads 'Welcome trimblesuper. You have super access rights.' The main header features the Trimble logo and the text 'Transforming the way the world works' on the left, and the title 'Thunderbolt NTP TS200' in large blue font on the right. Below the header, there is a sidebar on the left with a 'SYSTEM STATUS' section and an 'INTERFACE MANAGEMENT' section. The 'INTERFACE MANAGEMENT' section is expanded to show 'Serial Port' in orange text, along with other options: Ethernet, VLAN, SNMP, and Syslog. The main content area is titled 'Serial Port Configuration' and contains the following settings:


- Serial Port**
- Baud Rate**: 115200 (dropdown menu)
- Parity**: none
- Stop Bits**: 1

- **Baud Rate:** Serial port speed: 9600, 19200, 38400, 57600, 115200. The default value is 115200
- **Parity:** Serial port parity setting – even, none, odd
- **Stop Bits:** Serial port stop bit setting – 0 or 1

*NOTE – The parity and stop bits are for reference only and are not user configurable.*

## 5.6 Synchronization Management

### *NTP Time Server eth0*



- **NTP Protocol:** Enabled, disabled or default.
- **NTP Broadcast:** Enabled or disabled
- **NTP Broadcast IP:** Broadcast IP for NTP (has to be in same domain as that of port)
- **NTP Broadcast Interval:** Values between 4 and 17 representing  $2^4$ (16 secs) and  $2^{17}$ (36.4 hours)
- **NTP Broadcast TTL:** Values between 1 to 7 hops.

## NTP Time Server eth1

The screenshot displays the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button and a 'Disable auto-logout' checkbox. A welcome message reads 'Welcome trimblesuper. You have super access rights.' The main header features the Trimble logo and the product name 'Thunderbolt NTP TS200'. A left sidebar contains menu items: 'SYSTEM STATUS', 'INTERFACE MANAGEMENT', 'SYNCHRONIZATION MANAGEMENT', and 'NTP' (which is highlighted), with sub-items 'GNSS' and 'Output'. The main content area is titled 'NTP Configuration' and has tabs for 'Ethernet Port 0', 'Ethernet Port 1' (selected), 'NTP Security', and 'NTP Peers'. Under the 'Ethernet Port 1' tab, the 'NTP Server' is set to 'Enabled'. The 'NTP Broadcast' section includes a 'Disabled' dropdown, and three input fields for 'NTP Broadcast IP', 'NTP Broadcast Interval', and 'NTP Broadcast TTL', all of which currently contain a hyphen (-).

- **NTP Protocol:** Enabled, disabled or default.
- **NTP Broadcast:** Enabled or disabled
- **NTP Broadcast IP:** Broadcast IP for NTP (has to be in same domain as that of port)
- **NTP Broadcast Interval:** Values between  $2^4$ (16 secs) and  $2^{17}$ (36.4 hours)
- **NTP Broadcast TTL:** Values between 1 to 7 hops.

The screenshot displays the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button and a 'Disable auto-logout' checkbox. On the right, a welcome message reads 'Welcome trimblesuper. You have super access rights.' The main header features the Trimble logo and the title 'Thunderbolt NTP TS200'. Below the header, a sidebar on the left contains navigation options: 'SYSTEM STATUS', 'INTERFACE MANAGEMENT', 'SYNCHRONIZATION MANAGEMENT', and 'NTP' (with sub-items 'GNSS' and 'Output'). The main content area is titled 'NTP Configuration' and includes tabs for 'Ethernet Port 0', 'Ethernet Port 1', 'NTP Security' (which is active), and 'NTP Peers'. Under the 'NTP Security' tab, there are three fields: 'NTP Encryption' (set to 'Disabled'), 'System Hostname' (set to 'GM200RevD'), and 'Encryption Group' (set to '-'). A 'Renew Certificate' button is located below the 'Encryption Group' field.

- **NTP Encryption:** Disabled or Enabled
- **NTP Encryption Hostname:** Hostname of encryption certificate
- **NTP Encryption Group Name:** Group name for encryption certificate

## NTP Time Server - NTP Peers

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a "Logout" button, a "Disable auto-logout" checkbox, and a welcome message: "Welcome *trimblesuper*. You have *super* access rights." Below this is the Trimble logo and the text "Transforming the way the world works". The main title is "Thunderbolt NTP TS200". On the left side, there is a sidebar menu with the following items: "SYSTEM STATUS", "INTERFACE MANAGEMENT", "SYNCHRONIZATION MANAGEMENT", "NTP", "GNSS", and "Output". The main content area is titled "NTP Configuration" and has four tabs: "Ethernet Port 0", "Ethernet Port 1", "NTP Security", and "NTP Peers" (which is selected). Under the "NTP Peers" tab, there is a section titled "NTP Peers for Port 0 and Port 1" with four empty input fields for adding IP addresses.

- **NTP Peers :** IP Addresses of up to 4 NTP Peers, valid for Port0 and Port1.

The screenshot displays the web interface for the Trimble Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button and a 'Disable auto-logout' checkbox. The user is identified as 'trimblesuper' with 'super access rights'. The main title is 'Thunderbolt NTP TS200'. The left sidebar contains several menu items: 'SYSTEM STATUS', 'INTERFACE MANAGEMENT', 'SYNCHRONIZATION MANAGEMENT' (which is highlighted in orange), 'NTP', 'GNSS' (also highlighted in orange), 'Output', 'SECURITY MANAGEMENT', and 'SYSTEM MANAGEMENT'. The main content area is titled 'GNSS Configuration' and is divided into several sections:
 

- Constellation Selection:** Includes checkboxes for GPS (checked), GLONASS (checked), Beidou, Galileo, and QZSS.
- Position Settings:** Includes a 'Positioning Mode' dropdown set to 'Automatic'.
- Latitude (degrees):** Input field with value 19.45909.
- Longitude (degrees):** Input field with value -99.17947.
- Height (meters):** Input field with value 2247.38.
- Survey Length (secs):** Input field with value 2000.
- Elevation Mask:** Input field with value 10.0.
- PDOP Mask:** Input field with value 3.0.
- Signal Level Mask:** Input field with value 0.00.
- Receiver Status:** Displayed as 'Normal'.
- Receiver Mode:** Displayed as 'Overdet Clock (Time)'.
- Antenna Delay (ns):** Input field with value 0.

 At the bottom of the configuration area, there is a 'Restart GNSS Receiver' section with a dropdown menu currently set to 'Do nothing'.

- **GNSS Constellations:** Combination of GPS, GLONASS, Beidou, Galileo and/or QZSS
- **Positioning Mode:** Automatic, Surveyed or Manual
- **Latitude:** Latitude in degrees
- **Longitude:** Longitude in degrees
- **Height:** Height in meters
- **Elevation Mask:** Satellite elevation mask level
- **PDOP Mask:** Satellite PDOP mask level
- **Signal Level Mask:** Set signal level mask
- **Antenna Delay (ns):** Delay compensation of antenna cable.
- **Restart GNSS Engine:** Warm, Cold or Do Nothing

## Output Configuration

The screenshot displays the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button and a 'Disable auto-logout' checkbox. The user is identified as 'trimblesuper' with 'super access rights'. The main header features the Trimble logo and the product name 'Thunderbolt NTP TS200'. A left sidebar contains navigation options: 'SYSTEM STATUS', 'INTERFACE MANAGEMENT', 'SYNCHRONIZATION MANAGEMENT', 'NTP', 'GNSS', and 'Output' (which is highlighted). The main content area is titled 'Output Configuration' and is divided into three columns: 'Output Ports', 'Output Settings', and 'Periodic Settings'. Under 'Output Ports', the 'Sync Out' is set to 'PPS'. Under 'Output Settings', 'Width (ns)' is 1000 and 'Delay (ns)' is 0. Under 'Periodic Settings', 'Width (ns)' is 1000, 'Period (seconds)' is 10, and 'Value (0 - Period-1)' is 0.

- **BNC Output:** The type of out signal – PPS, PP2S, Periodic or 10MHz
- **Output Width:** Width of Output in nS
- **Output Delay:** Delay of Output in nS
- **Periodic Width:** Periodic width in ns
- **Period:** Period in seconds
- **Periodic Value:** Periodic value

## 5.7 Security Management

### User Management - Active Sessions

The screenshot displays the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button and a 'Disable auto-logout' checkbox. A welcome message reads 'Welcome trimblesuper. You have super access rights.' The main header features the Trimble logo and the title 'Thunderbolt NTP TS200'. A left sidebar contains menu items: SYSTEM STATUS, INTERFACE MANAGEMENT, SYNCHRONIZATION MANAGEMENT, SECURITY MANAGEMENT (highlighted), and User Authentication. The main content area is titled 'User Management' and includes tabs for 'Active Sessions', 'Users Accounts', and 'Password Rules'. The 'Active Sessions' tab is selected, showing a table with the following data:

	Name	Email	Service	Active
You	trimblesuper		Rem-37.13.44.93	23 mins

Below the table is a 'User Logoff' button.

- **Name:** Existing username
- **Email:** Updated email
- **Service:** IP Address used to connect to
- **Active:** The time that the session has been active

## User Management - User Accounts

Logout  Disable auto-logout

Welcome *trimblesuper*.  
You have *super* access rights.

**Trimble**  
Transforming the way the world works

# Thunderbolt NTP TS200

## User Management

Active Sessions | **Users Accounts** | Password Rules

### Account Management

Select Action:  Username:  Access Level:

Email:  Password:  Confirm Password:

### User Account Selection

	User	Level	Email
<input checked="" type="checkbox"/>	trimblesuper	super	
<input checked="" type="checkbox"/>	trimbleadmin	admin	
<input type="checkbox"/>	trimble	user	

- **Select Action:** No Action, Add, Modify, Delete
- **Username:** New username to be added
- **Password:** New password to be chosen
- **Confirm Password:** Confirm password. Should be same as password.
- **Access Level:** User, Admin or Super(visor)
- **Email:** New email
- **User Account Selection:** This is a list of all users created in TS200

The screenshot shows the Thunderbolt NTP TS200 web interface. At the top, there is a navigation bar with a 'Logout' button, a 'Disable auto-logout' checkbox, and a welcome message: 'Welcome trimblesuper. You have super access rights.' Below this is the Trimble logo and the title 'Thunderbolt NTP TS200'. The main content area is titled 'User Management' and has three tabs: 'Active Sessions', 'Users Accounts', and 'Password Rules' (which is selected). The 'Password Rules' tab contains several configuration options:

- Preconfigured password criteria:** A dropdown menu set to 'None'.
- Require different password when password is changed:** A dropdown menu set to 'Yes'.
- Password rule complexity metric:** A text input field containing the value '6'.
- Minimum number of characters in password:** A text input field containing the value '6'.
- Minimum number of lowercase letter:** A text input field containing the value '0'.
- Minimum number of uppercase letter:** A text input field containing the value '0'.
- Minimum number of digits:** A text input field containing the value '0'.
- Minimum number of other characters:** A text input field containing the value '0'.

On the left side of the interface, there is a sidebar menu with the following items: 'SYSTEM STATUS', 'INTERFACE MANAGEMENT', 'SYNCHRONIZATION MANAGEMENT', 'SECURITY MANAGEMENT' (highlighted in orange), 'User Authentication' (highlighted in orange), and 'SYSTEM MANAGEMENT'.

- **Preconfigured password criteria:** 5 criteria of password already configured
  - o None the password doesn't require any rule to be accepted by TS200
  - o p0: 6 characters as minimum (complexity = 6)
  - o p1: 7 characters as minimum, 1 uppercase letter as minimum (complexity 8)
  - o p2: 9 characters as minimum, 1 uppercase letter as minimum  
2 lowercase letter as minimum (complexity 12)
  - o p3 10 characters as minimum, 1 uppercase letter as minimum  
2 lowercase letter as minimum, 1 digit as minimum (complexity 14)
  - o p4 11 characters as minimum, 1 uppercase letter as minimum  
2 lowercase letter as minimum, 1 digit as minimum,  
1 other character as minimum (complexity 16)
- **Require different password when password is changed:** Yes or No. It sets if the user is required to enter a different password when changing their password
- **Password rule complexity metric:** the sum of all conditions configured
- **Minimum number of characters in password:** password requires <n> characters as minimum
- **Minimum number of lowercase letter:** password requires <n> lowercase letters as minimum
- **Minimum number of uppercase letter:** password requires <n> uppercase letters as minimum
- **Minimum number of digits:** password requires <n> digits as minimum
- **Minimum number of other characters:** password requires <n> other characters as minimum. These other characters can be any printable character, except for space.

## Authentication Portal

Logout  Disable auto-logout

Welcome *trimblesuper*.  
You have *super* access rights.

**Trimble**  
Transforming the way the world works

# Thunderbolt NTP TS200

### Authentication Configuration

Portal RADIUS TACACS+

Portal Authentication Selection

Type	SSH	Telnet	Web	Serial	SNMP
Local	<input checked="" type="radio"/>				
Radius	<input type="radio"/>				
Tacacs+	<input type="radio"/>				
Disable	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Set Defaults

This page shows the authentication type Local, Radius or TACACS+ with the three different portal types: SSH, Telnet or Web.

'Set Defaults' button sets the authentication to the default values.


Disable option allow to disable telnet access to TS200.

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button and a 'Disable auto-logout' checkbox. On the right, a welcome message reads 'Welcome *trimblesuper*. You have *super* access rights.' The main header features the Trimble logo and the title 'Thunderbolt NTP TS200'. Below the header is a sidebar with navigation options: SYSTEM STATUS, INTERFACE MANAGEMENT, SYNCHRONIZATION MANAGEMENT, SECURITY MANAGEMENT (highlighted), User Authentication (highlighted), and SYSTEM MANAGEMENT. The main content area is titled 'Authentication Configuration' and has three tabs: Portal, RADIUS (selected), and TACACS+. Under the RADIUS tab, there are 'RADIUS Settings' and a 'RADIUS Dictionary for GM200' section. The RADIUS Settings section includes fields for Primary Server Address (0.0.0.0), Secondary Server Address (0.0.0.0), Protocol Port (1812), and Server Time Out (3). There is also a Secret field with a hyphen and a 'Set Defaults' button. The RADIUS Dictionary section contains a text area with the following content:

```
# Copyright (c) Trimble, Inc.
# RADIUS Dictionary for the Thunderbolt GM200
# Access Levels: 1 user, 3 admin, 5 super
VENDOR      Trimble      46285
BEGIN-VENDOR Trimble
ATTRIBUTE   Trimble-AdminLevel 10 integer
END-VENDOR  Trimble
```

- **Primary Address:** Displays or allows to enter the primary server address for the RADIUS server.
- **Secondary Address:** Displays or allows to enter the secondary server address for the RADIUS server.
- **Protocol Port:** Displays or allows to set the IP port for the RADIUS server (same for primary and secondary).
- **Server Time Out:** Sets the RADIUS server timeout value. 1-60 seconds.
- **Secret:** Sets the shared secret value for the RADIUS server
- **RADIUS Dictionary**
- **Set Defaults Button:** Sets the RADIUS server information to defaults.

# Authentication TACACS+



- **Primary Address:** Displays or allows to enter the primary server address for the TACACS+ server.
- **Secondary Address:** Displays or allows to enter the secondary server address for the TACACS+ server.
- **Protocol Port:** Displays or allows to set the IP port for the TACACS+ server (same for primary and secondary).
- **Server Time Out:** Sets the TACACS+ server timeout value. 1-60 seconds.
- **Protocol Type:** Sets the TACACS+ server protocol string
- **Service Type:** Sets the TACACS+ server service string
- **Secret:** Sets the shared secret value for the RADIUS server
- **Set Defaults Button:** Sets the TACACS+ server information to defaults.

## 5.8 System Management

### Alarm Configuration

Logout  Disable auto-logout Welcome *trimblesuper*.  
You have *super* access rights.

**Trimble** Transforming the way the world works

# Thunderbolt NTP TS200

## Alarm Configuration

Alarm No.  Name  Level  Set Time  Clear Time

Alm #	Description	Level	Set Time	Clr Time	Set	Alm #	Description	Level	Set Time	Clr Time	Set
0	GNSS-Comm-E1	CRI	0	0	No	14	PPS-Sync-Bad	MAJ	5	10	No
1	GNSS-Comm-E2	CRI	0	0	No	15	Freq-Out-Bad	MAJ	0	10	No
2	GNSS-Comm-Loss	CRI	2	5	No	17	FPGA-Load-Bad	CRI	0	0	No
3	GNSS-Ant-Shorted	MIN	0	2	No	18	GNSS-Pos-Integrity	MIN	60	2	No
4	GNSS-Ant-Open	MIN	0	2	No	19	UTC-Corr-Unk	MAJ	0	0	No
5	GNSS-Track-No	MIN	0	2	No	20	Eth-Port0-Down	MAJ	0	2	Yes
7	GNSS-PPS-Loss	MIN	0	10	No	21	Eth-Port1-Down	MAJ	0	2	Yes
9	Freq-Range-Bad	CRI	0	10	No	22	Eth-Mgmt-Down	MAJ	0	2	No
11	GNSS-Time-Bad	MIN	0	0	No	23	Eth-Same-Subnet	CRI	0	0	No
12	Freq-Loop-Unlock	MIN	2	5	No	26	Time-Set-Bad	CRI	0	0	No
13	Freq-Hold-Exceed	MAJ	0	0	No						

- **Alarm No.:** Select the alarm number to be configured.
- **Level:** IGN(ignored), NFY(notification), MIN(minor),MAJ(major) or CRI(critical)
- **setTime:** Time for which the alarm condition must be active before it is set
- **clrTime:** Time for which alarm condition is inactive before it is cleared

*The table shows the list of available alarms along with their current level, set and clear time.  
The table allows changing the severity level, the set and clear time.*

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button and a 'Disable auto-logout' checkbox. On the right, a welcome message reads 'Welcome trimblesuper. You have super access rights.' The main header features the Trimble logo and the text 'Transforming the way the world works' on the left, and the product name 'Thunderbolt NTP TS200' in large blue letters on the right. Below the header is a sidebar menu with several categories: 'SYSTEM STATUS', 'INTERFACE MANAGEMENT', 'SYNCHRONIZATION MANAGEMENT', 'SECURITY MANAGEMENT', 'SYSTEM MANAGEMENT' (highlighted in orange), and 'Alarm System' (with 'System' in orange). The main content area is titled 'System Configuration' and contains two tabs: 'System Configuration' (active) and 'System Firmware'. Under the 'System Configuration' tab, there is a 'System Hostname' field with the value 'GM200RevD'. Below this, there is a section titled 'System Configuration' with buttons for 'Save User Config' and 'Load User Config'. A file upload area shows 'Choose File' and 'No file chosen'. Below that are buttons for 'Upload Config File' and 'Download Config File'. At the bottom, there is a section titled 'Supervisor Options' with buttons for 'Load Factory Config' and 'System Reboot'.

This tab allows Users to Configure System with following options:-

- **Save Configuration**
- **Download Configuration**
- **Upload Configuration**
- **Set Factory Config**
- **System Reboot**

## System Software Upload

This page displays the Current System version running on Thunderbolt TS200 along with the current GNSS version and current FPGA version.

This page allows users to upload the Thunderbolt TS200 firmware package to the system.

The uploading of the package doesn't automatically update the system firmware. Another step to "Update System" is required.

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a "Logout" button and a "Disable auto-logout" checkbox. A welcome message reads "Welcome trimblesuper. You have super access rights." The main header features the Trimble logo and the text "Transforming the way the world works" followed by "Thunderbolt NTP TS200".

On the left side, there is a vertical menu with several options: "SYSTEM STATUS", "INTERFACE MANAGEMENT", "SYNCHRONIZATION MANAGEMENT", "SECURITY MANAGEMENT", "SYSTEM MANAGEMENT" (highlighted in orange), and "Alarm System".

The main content area is titled "System Configuration" and has two tabs: "System Configuration" and "System Firmware" (the active tab). Under the "System Firmware" tab, there is a table showing the current versions:

Current System Version	Current GNSS Version	Current FPGA Version
20180204-0.0.9.0	20170515-1.4.0.0	18.3.15

Below the table is a section for "Firmware Patch Staging". It includes a "Choose File" button, a "No file chosen" message, an "Upload Patch File" button, and a "Reset Upload" button.

At the bottom, there are two columns of "System Patches" and "GNSS Patches". The "System Patches" column lists three options with radio buttons: "20171003-0.0.7.0.pkg", "20171212-0.0.7.0+.pkg", and "20180204-0.0.9.0.pkg". The "GNSS Patches" column lists two options with radio buttons: "ResSMT360\_v1\_03.bin" and "ResSMT360\_v1\_04.5.bin".

At the very bottom of the interface, there are two buttons: "Update System" and "Unstage Patch".

**NOTE** – The software upload tab is available when logged with super user level access.



## Chapter 6: SNMP Support

In this chapter:

[SNMP Overview](#)  
[SNMP Traps & MIB](#)

This chapter describes the SNMP and SNMP notification setting procedure for Thunderbolt NTP Time Server Clock.

## 6.1 SNMP Overview

Simple Network Management Protocol (SNMP) is an Internet-standard application-layer protocol for managing and monitoring network elements. It has been defined by the Internet Engineering Task Force (IETF) under RFC 1157 for exchanging management information between network devices.

An SNMP-managed network consists of three key components:

- Managed device
- Agent — software which runs on managed devices
- Network management station (NMS) — software which runs on the manager

SNMP agents expose management data on the managed systems as variables. The variables accessible via SNMP are organized in hierarchies. These hierarchies, and other metadata (such as type and description of the variable), are described by Management Information Bases (MIBs).

Thunderbolt TS200 supports SNMP v2c.

## 6.2 SNMP Traps

SNMP traps enable an agent to notify the management station of significant events by way of an unsolicited SNMP message.

Thunderbolt NTP Time Server Clock TS200 provides a command line interface to enable the traps. (Refer to [Chapter 4: Command Line Interface Reference](#))

## 6.3 Accessing the SNMP MIB Files

Thunderbolt NTP Time Server Clock TS200's private MIB files can be downloaded through the WebUI of the system. The MIB download option is available under the "Interface Management" tab of the unit.

The Thunderbolt NTP Time Server Clock TS200's SNMP MIB consist of two files:

- TRIMBLE-MIB.mib
- TRIMBLE-TBLT-MIB.mib

## Chapter 7: TS200 Provisioning

In this chapter:


CLI Command Set for  
provisioning

WebUI used

This chapter describes the basic TS200 configuration steps when customer will interact with the first time. There are examples of CLI commands used for provisioning, as well the equivalent Web UI configuration.

## 7.1 Help Commands

### 7.1.1 help set



```
TS200 Configuration Commands
>
>
> help set
Use this command to change system settings. This command must be used
with sub-commands. You can:

set alarm          - configure system alarms
set auth           - configure login authentication
set comm           - configure comm port setting
set dlog           - start/stop the datalogger datalogger
set freq           - issue commands to frequency control
set gnss           - configure the GNSS settings
set input          - configure reference inputs
set network        - configure network connection
set ntp            - configure ntp settings
set output         - configure output signal settings
set periodic       - configure periodic signal settings
set snmp           - configure SNMP settings
set syslog         - configure the syslog server connection
set user           - configure the system users

>
>
>
```

There is not an equivalent in WebUI since this web user interface is very intuitive.

## 7.1.2 help set ntp

```
TS200 Configuration Commands
> help set ntp
Use this command to configure the NTP broadcast information.

Format:

  set ntp [eth0|eth1] <options>

The port information (eth0|eth1) must be supplied for options marked
with an '*'. They are optional on other commands, unless noted.

Where <options> are:

  disable      Disable NTP for the given port. This stops all
               NTP traffic for the port.
  enable      Enable NTP for the given port. This starts NTP
               traffic for the port.
  default     Restore default settings for the port, if
               supplied. If no port supplied then all ports
               are affected. This option may not be used with
               any other options.
  *bcast <ip>|off  Set broadcasting on/off for the port. If an <ip>
               address is given, it must be in the same domain
               as the domain of the port. This is to keep from
               broadcasting to the whole Internet.
  *interval <n>   Set the broadcast time interval to <n> where <n>
               is the broadcast time interval, in seconds to
               the power of two. For example, a minpoll value
               of 4 sets the broadcast time interval to 2^4 or
               16 seconds. Allowable values are from 4 (16 sec)
               to 17 (36.4 hours).
  *ttl <t>       Set the time-to-live hops to <t>. Allowable values
               are from 1 to 7, or '-'. Note that a value of
               '-' sets the default maximum hop value allowed.
  encrypt on|off  Set the encryption of the NTP messages on/off.
  host <hn>      Set the host name for the encryption certificate
               to <hn>. Only the characters '_', 0-9, A-Z, and
               a-z are valid within the host name. The max size
               of the host name is 32 characters.
  group <gn>     Set the group name for the encryption certificate
               to <gn>. Only the characters '_', 0-9, A-Z, and
               a-z are valid within the group name. If the name
               is set to '-' then the group is disabled for the
               security. The max size of the group name is 32
               characters.
  peer <pl>      Set the peer list to <pl>. <pl> may be a comma
               separated list of up to 4 peers to use. This list
               must contain no spaces and may be made up of a
               mixture of IPv4, IPv6 or valid hostnames. The other
               allowable <pl> option is '-', which disables peering
               (regardless of where it is in the list).
  iff          This will renew the IFF certificate for NTP
               certification. This should be done approximately
               every 30 days to keep the certificate valid.

Examples:
  set ntp eth1 bcast 10.1.140.255 interval 4
  set ntp encrypt on host Trimble group MyGroup1
  set ntp peer 192.168.0.80,10.1.140.80,time.nist.gov

>
>
```

'set ntp' command is divided in three sections in WebUI. Please select

- Synchronization Management -> NTP and select the Ethernet port to be configured: eth0 or eth1. In this section, it is possible (Image 7.1.2.1):
  - to enable/disable NTP Server
  - to enable/disable NTP Broadcast
  - To configure NTP Broadcast IP
  - To configure NTP Broadcast Interval
  - To configure NTP Broadcast TTL
- Synchronization Management -> NTP -> NTP Security. In this section, it is possible (Image 7.1.2.2):
  - To enable/disable NTP Encryption
  - To configure the system hostname
  - To configure the encryption group
- Synchronization Management -> NTP -> NTP Peers. In this section, it is possible (Image 7.1.2.3):
  - To configure 4 valid IP address working as NTP Peers for eth0 and eth1




Image 7.1.2.1



Image 7.1.2.2






Image 7.1.2.3

## 7.2 View System and Hardware Version

### 7.2.1 view version



## 7.2.2 view prodconf

```
TS200 Configuration Commands
>
>
>
>
>
>
>
>
>
>
> view prodconf
Serial Number: 1370000073
  Build Date: 09/01/2017 15
Premium bits: 0000001D
  Product ID: 111224-50
  Hardware ID: 111222-00
Extended S/N:
>
>
>
>
>
>
```

Logout  Disable auto-logout Welcome *trimblesuper*.  
You have *super* access rights.

 **Thunderbolt NTP TS200**

Transforming the way the world works

### SYSTEM STATUS

- Alarms and Events
- System Info**
- Timing
- GNSS
- Network

### INTERFACE MANAGEMENT

### SYNCHRONIZATION MANAGEMENT

### SECURITY MANAGEMENT

### SYSTEM MANAGEMENT

### System Information

<b>Product ID</b> 111224-50	<b>Time (UTC)</b> 02/28/2018 14:23
<b>Hardware ID</b> 111222-00	<b>Up Time</b> 14:52
<b>Serial Number</b> 1370000073	<b>CPU Load Average</b> 15 %
<b>Extended S/N</b> -	<b>System Temperature</b> 33.0 °C
<b>Software Version</b> 20180204-0.0.9.0	<b>Memory - Active</b> 208180 kB
<b>Hardware Build Date</b> 09/01/2017 15	<b>Memory - Available</b> 954272 kB

[Download Support Info](#)

**Realtime Graph View**

[System Stats](#) [Close Graph](#)

## 7.3 View Alarms, Status and Firmware

### 7.3.1 get alarm

```

TS200 Configuration Commands
>
> get alarm
Current alarm settings:
#           Alarm Desc           Level   Set Time   Clr Time
-----
0           GNSS-Comm-E1                   CRI     0           0
1           GNSS-Comm-E2                   CRI     0           0
2           GNSS-Comm-Loss                 CRI     2           5
3           GNSS-Ant-Shorted             MIN     0           2
4           GNSS-Ant-Open                 MIN     0           2
5           GNSS-Track-No                 MIN     0           2
7           GNSS-PPS-Loss                 MIN     0           10
9           Freq-Range-Bad                 CRI     0           10
11          GNSS-Time-Bad                 MIN     0           0
12          Freq-Loop-Unlock             MIN     2           5
13          Freq-Hold-Exceed             MAJ     0           0
14          PPS-Sync-Bad                 MAJ     5           10
15          Freq-Out-Bad                 MAJ     0           10
17          FPGA-Load-Bad                 CRI     0           0
18          GNSS-Pos-Integrity          MIN     60          2
19          UTC-Corr-Unk                 MAJ     0           0
20          Eth-Port0-Down              MAJ     0           2
21          Eth-Port1-Down              MAJ     0           2
22          Eth-Mgmt-Down                MAJ     0           2
23          Eth-Same-Subnet              CRI     0           0
26          Time-Set-Bad                 CRI     0           0
>

```

Logout  Disable auto-logout
Welcome *trimblesuper*.  
You have *super* access rights.

# Thunderbolt NTP TS200

SYSTEM STATUS

INTERFACE MANAGEMENT

SYNCHRONIZATION MANAGEMENT

SECURITY MANAGEMENT

SYSTEM MANAGEMENT

Alarm System

### Alarm Configuration

Alarm No. 
Name 
Level 
Set Time 
Clear Time

Alm #	Description	Level	Set Time	Clr Time	Set	Alm #	Description	Level	Set Time	Clr Time	Set
0	GNSS-Comm-E1	CRI	0	0	No	14	PPS-Sync-Bad	MAJ	5	10	No
1	GNSS-Comm-E2	CRI	0	0	No	15	Freq-Out-Bad	MAJ	0	10	No
2	GNSS-Comm-Loss	CRI	2	5	No	17	FPGA-Load-Bad	CRI	0	0	No
3	GNSS-Ant-Shorted	MIN	0	2	No	18	GNSS-Pos-Integrity	MIN	60	2	No
4	GNSS-Ant-Open	MIN	0	2	No	19	UTC-Corr-Unk	MAJ	0	0	No
5	GNSS-Track-No	MIN	0	2	No	20	Eth-Port0-Down	MAJ	0	2	Yes
7	GNSS-PPS-Loss	MIN	0	10	No	21	Eth-Port1-Down	MAJ	0	2	Yes
9	Freq-Range-Bad	CRI	0	10	No	22	Eth-Mgmt-Down	MAJ	0	2	No
11	GNSS-Time-Bad	MIN	0	0	No	23	Eth-Same-Subnet	CRI	0	0	No
12	Freq-Loop-Unlock	MIN	2	5	No	26	Time-Set-Bad	CRI	0	0	No
13	Freq-Hold-Exceed	MAJ	0	0	No						

## 7.3.2 view logs

```
TS200 Configuration Commands
>
>
>
>
>
>
>
>
>
>
> view logs
2018-02-28 07:54:03.808 scgi : Firmware update ended.
2018-02-28 07:54:13.033 scgi : Firmware update started.
2018-02-28 07:54:14.801 scgi : Firmware update ended.
2018-02-28 07:54:24.025 scgi : Firmware update started.
2018-02-28 07:54:25.798 scgi : Firmware update ended.
2018-02-28 07:54:34.607 scgi : Firmware update started.
2018-02-28 07:54:36.418 scgi : Firmware update ended.
2018-02-28 07:54:45.579 scgi : Firmware update started.
2018-02-28 07:54:47.383 scgi : Firmware update ended.
2018-02-28 07:54:56.575 scgi : Firmware update started.
2018-02-28 07:54:58.440 scgi : Firmware update ended.
2018-02-28 07:55:08.025 scgi : Firmware update started.
2018-02-28 07:55:09.808 scgi : Firmware update ended.
2018-02-28 07:55:12.006 cfg : 'trimblesuper' LOGOUT as super on Rem-37.13.44.93
2018-02-28 13:52:52.171 cfg : 'vcruz' LOGIN as super on Rem-::ffff:37.13.44.93:51046
2018-02-28 14:04:11.621 cfg : 'vcruz' LOGOUT as super on Rem-::ffff:37.13.44.93:51046
2018-02-28 14:08:36.530 cfg : 'vcruz' LOGIN as super on Rem-::ffff:37.13.44.93:51233
2018-02-28 14:09:52.724 cfg : 'trimblesuper' LOGIN as super on Rem-37.13.44.93
2018-02-28 14:19:01.208 cfg : 'vcruz' LOGOUT as super on Rem-::ffff:37.13.44.93:51233
2018-02-28 14:24:38.996 cfg : 'vcruz' LOGIN as super on Rem-::ffff:37.13.44.93:52212
>
>
>
>
>
>
```

```
TS200 Configuration Commands
>
>
>
>
>
>
>
>
>
>
> view logs cfg
2018-02-28 00:08:59.536 cfg : 'vcruz' LOGOUT as super on Rem-37.13.44.93
2018-02-28 00:28:10.866 cfg : Save user configuration
2018-02-28 00:28:30.539 cfg : 'vcruz' LOGIN as super on Rem-37.13.44.93
2018-02-28 00:29:07.155 cfg : 'vcruz' LOGOUT as super on Rem-37.13.44.93
2018-02-28 00:29:41.434 cfg : 'vcruz' LOGIN as super on Rem-37.13.44.93
2018-02-28 00:29:56.700 cfg : 'vcruz' LOGOUT as super on Rem-37.13.44.93
2018-02-28 00:30:05.840 cfg : 'vcruz' LOGIN as super on Rem-37.13.44.93
2018-02-28 00:30:35.176 cfg : 'vcruz' LOGOUT as super on Rem-37.13.44.93
2018-02-28 00:31:03.989 cfg : 'vcruz' LOGIN as super on Rem-37.13.44.93
2018-02-28 00:42:34.359 cfg : 'vcruz' LOGOUT as super on Rem-37.13.44.93
2018-02-28 05:49:38.456 cfg : 'vcruz' LOGIN as super on Rem-::ffff:37.13.44.93:65275
2018-02-28 06:08:23.158 cfg : 'vcruz' LOGOUT as super on Rem-::ffff:37.13.44.93:65275
2018-02-28 07:15:09.543 cfg : 'trimblesuper' LOGIN as super on Rem-37.13.44.93
2018-02-28 07:55:12.006 cfg : 'trimblesuper' LOGOUT as super on Rem-37.13.44.93
2018-02-28 13:52:52.171 cfg : 'vcruz' LOGIN as super on Rem-::ffff:37.13.44.93:51046
2018-02-28 14:04:11.621 cfg : 'vcruz' LOGOUT as super on Rem-::ffff:37.13.44.93:51046
2018-02-28 14:08:36.530 cfg : 'vcruz' LOGIN as super on Rem-::ffff:37.13.44.93:51233
2018-02-28 14:09:52.724 cfg : 'trimblesuper' LOGIN as super on Rem-37.13.44.93
2018-02-28 14:19:01.208 cfg : 'vcruz' LOGOUT as super on Rem-::ffff:37.13.44.93:51233
2018-02-28 14:24:38.996 cfg : 'vcruz' LOGIN as super on Rem-::ffff:37.13.44.93:52212
>
>
>
>
>
>
```



# Thunderbolt NTP TS200



**SYSTEM STATUS**

- Alarms and Events
- System Info
- Timing
- GNSS
- Network

**INTERFACE MANAGEMENT**

**SYNCHRONIZATION MANAGEMENT**

**SECURITY MANAGEMENT**

**SYSTEM MANAGEMENT**

### Alarm Status and Event Log

Alarms | **Event Log**

Event Filter: All | Number of Events: All | Download Log | Clear Log

```
2018-02-28 14:57:05.848 scgi : Firmware update ended.
2018-02-28 14:57:04.083 scgi : Firmware update started.
2018-02-28 14:54:21.816 cll : Firmware update ended.
2018-02-28 14:54:21.795 cll : Firmware update started.
2018-02-28 14:53:00.806 gns : voruz@Rem-::ffff:37.13.44.93:52212: Changed BNC output to 10MHz
2018-02-28 14:50:28.170 cfg : 'trimblesuper' LOGIN as super on Rem-37.13.44.93
2018-02-28 14:49:53.052 freq : Output stratum changed to 0 (quality 7)
2018-02-28 14:49:43.052 freq : Changing loop control from Recover to Lock
2018-02-28 14:49:12.048 freq : Changing loop control from Hold to Recover
2018-02-28 14:49:11.558 freq : Output stratum changed to 2 (quality 6)
2018-02-28 14:49:02.078 freq : Changing selected input from None to GNSS
2018-02-28 14:49:02.055 freq : Clock GNSS stratum changed to 0 (quality 7)
2018-02-28 14:49:00.553 freq : Changing loop control from Lock to Hold
2018-02-28 14:48:47.554 freq : Output stratum changed to 5 (quality 3)
2018-02-28 14:48:46.503 freq : Changing selected input from GNSS to None
2018-02-28 14:37:44.150 alarm : Set alarm 20, 'Eth-Port0-Down'
2018-02-28 14:37:08.525 alarm : Clear alarm 20, 'Eth-Port0-Down'
2018-02-28 14:34:29.014 cfg : 'trimblesuper' LOGOUT as super on Rem-37.13.44.93
2018-02-28 14:24:38.996 cfg : 'voruz' LOGIN as super on Rem-::ffff:37.13.44.93:52212
2018-02-28 14:19:01.208 cfg : 'voruz' LOGOUT as super on Rem-::ffff:37.13.44.93:51233
2018-02-28 14:09:52.724 cfg : 'trimblesuper' LOGIN as super on Rem-37.13.44.93
2018-02-28 14:08:36.530 cfg : 'voruz' LOGIN as super on Rem-::ffff:37.13.44.93:51233
2018-02-28 14:04:11.621 cfg : 'voruz' LOGOUT as super on Rem-::ffff:37.13.44.93:51046
2018-02-28 13:52:52.171 cfg : 'voruz' LOGIN as super on Rem-::ffff:37.13.44.93:51046
2018-02-28 07:55:12.006 cfg : 'trimblesuper' LOGOUT as super on Rem-37.13.44.93
2018-02-28 07:55:09.808 scgi : Firmware update ended.
```



# Thunderbolt NTP TS200



**SYSTEM STATUS**

- Alarms and Events
- System Info
- Timing
- GNSS
- Network

**INTERFACE MANAGEMENT**

**SYNCHRONIZATION MANAGEMENT**

**SECURITY MANAGEMENT**

**SYSTEM MANAGEMENT**

### Alarm Status and Event Log

Alarms | **Event Log**

Event Filter: Config Mo... | Number of Events: All | Download Log | Clear Log

```
2018-02-28 14:50:28.170 cfg : 'trimblesuper' LOGIN as super on Rem-37.13.44.93
2018-02-28 14:34:29.014 cfg : 'trimblesuper' LOGOUT as super on Rem-37.13.44.93
2018-02-28 14:24:38.996 cfg : 'voruz' LOGIN as super on Rem-::ffff:37.13.44.93:52212
2018-02-28 14:19:01.208 cfg : 'voruz' LOGOUT as super on Rem-::ffff:37.13.44.93:51233
2018-02-28 14:09:52.724 cfg : 'trimblesuper' LOGIN as super on Rem-37.13.44.93
2018-02-28 14:08:36.530 cfg : 'voruz' LOGIN as super on Rem-::ffff:37.13.44.93:51233
2018-02-28 14:04:11.621 cfg : 'voruz' LOGOUT as super on Rem-::ffff:37.13.44.93:51046
2018-02-28 13:52:52.171 cfg : 'voruz' LOGIN as super on Rem-::ffff:37.13.44.93:51046
2018-02-28 07:55:12.006 cfg : 'trimblesuper' LOGOUT as super on Rem-37.13.44.93
2018-02-28 07:15:09.543 cfg : 'trimblesuper' LOGIN as super on Rem-37.13.44.93
2018-02-28 06:08:23.158 cfg : 'voruz' LOGOUT as super on Rem-::ffff:37.13.44.93:65275
2018-02-28 05:49:38.456 cfg : 'voruz' LOGIN as super on Rem-::ffff:37.13.44.93:65275
2018-02-28 00:42:34.359 cfg : 'voruz' LOGOUT as super on Rem-37.13.44.93
2018-02-28 00:31:03.989 cfg : 'voruz' LOGIN as super on Rem-37.13.44.93
2018-02-28 00:30:35.176 cfg : 'voruz' LOGOUT as super on Rem-37.13.44.93
2018-02-28 00:30:05.840 cfg : 'voruz' LOGIN as super on Rem-37.13.44.93
2018-02-28 00:29:56.700 cfg : 'voruz' LOGOUT as super on Rem-37.13.44.93
2018-02-28 00:29:41.434 cfg : 'voruz' LOGIN as super on Rem-37.13.44.93
2018-02-28 00:28:07.155 cfg : 'voruz' LOGOUT as super on Rem-37.13.44.93
2018-02-28 00:28:10.866 cfg : 'voruz' LOGIN as super on Rem-37.13.44.93
2018-02-28 00:28:10.866 cfg : Save user configuration
2018-02-28 00:08:59.536 cfg : 'voruz' LOGOUT as super on Rem-37.13.44.93
2018-02-28 00:07:24.383 cfg : 'voruz' LOGOUT as super on Rem-::ffff:37.13.44.93:59036
2018-02-27 23:57:43.049 cfg : 'voruz' LOGIN as super on Rem-37.13.44.93
2018-02-27 23:57:12.480 cfg : 'voruz' LOGIN as super on Rem-::ffff:37.13.44.93:59036
2018-02-27 23:54:52.383 cfg : 'voruz' LOGOUT as super on Rem-::ffff:37.13.44.93:57233
```







# 7.5 Network Configuration

## 7.5.1 get network

```
TS200 Configuration Commands
>
>
> get network

Current settings for eth0:
  Status: Not Connected
  IPv4Mode: Static
  Address: 1.1.1.251
  Mask: 255.255.255.0
  Broadcast: 1.1.1.255
  Gateway: 1.1.1.1
  IPv6Mode: Static
  IPv6 Addr: fd6b:fd64:9e0c::/128 Scope:Global

Current settings for eth1:
  Status: Not Connected
  IPv4Mode: Static
  Address: 4.4.4.251
  Mask: 255.255.255.0
  Broadcast: 4.4.4.255
  Gateway:
  IPv6Mode: Static
  IPv6 Addr: fd6b:fd64:9e0c:1::/128 Scope:Global

Current settings for eth2:
  Status: Connected 100MB
  IPv4Mode: Static
  Address: 37.13.44.151
  Mask: 255.255.255.0
  Broadcast: 37.13.44.255
  Gateway: 37.13.44.1
  IPv6Mode: Static
  IPv6 Addr: fd6b:fd64:9e0c:2::/128 Scope:Global
  IPv6 Addr: fe80::217:47ff:fe7f:feb4/64 Scope:Link
>
>
```

Note: Each network interface should be on different subnet

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with 'Logout' and 'Disable auto-logout' on the left, and a welcome message 'Welcome trimblesuper. You have super access rights.' on the right. The main header displays the 'Thunderbolt NTP TS200' logo and name. Below the header is a sidebar with navigation options: SYSTEM STATUS, INTERFACE MANAGEMENT (selected), Ethernet (selected), VLAN, SNMP, Syslog, Serial Port, SYNCHRONIZATION MANAGEMENT, SECURITY MANAGEMENT, and SYSTEM. The main content area is titled 'Ethernet Configuration' and shows settings for 'Ethernet Port 0'. The 'Port Configuration' is set to 'Static' and the 'Connection Status' is 'Not Connected'. Under 'IPv4 Assignments', the 'Address' is 1.1.1.251, 'Subnet Mask' is 255.255.255.0, 'Gateway' is 1.1.1.1, and 'Broadcast' is 1.1.1.255. Under 'IPv6 Assignments', the 'IPv6 Mode' is 'Static', the 'Address' is fd6b:fd64:9e0c::/128, and the 'Scope' is 'Global'. At the bottom, there are input fields for 'IPv4 Address' and 'IPv6 Address' (both containing '<IPv4 address to ping>' and '<IPv6 address to ping>' respectively) and buttons for 'Ping IPv4' and 'Ping IPv6'.

## 7.5.2 set network

```
TS200 Configuration Commands
>
>
> set network eth0 disable
Interface: eth0
Disabling interface
> set network eth0 addr 1.1.1.251 mask 255.255.255.0 gateway 1.1.1.1
Interface: eth0
Setting IP address to 1.1.1.251
Setting network mask to 255.255.255.0
Setting gateway address to 1.1.1.1
>
>
```

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a "Logout" button, a "Disable auto-logout" checkbox, and a welcome message: "Welcome *trimblesuper*. You have *super* access rights." The main header displays the "Thunderbolt NTP TS200" logo and the tagline "Transforming the way the world works".

The left sidebar contains a navigation menu with the following categories and items:

- SYSTEM STATUS
- INTERFACE MANAGEMENT
  - Ethernet
  - VLAN
  - SNMP
  - Syslog
  - Serial Port
- SYNCHRONIZATION MANAGEMENT
- SECURITY MANAGEMENT
- SYSTEM MANAGEMENT

The main content area is titled "Ethernet Configuration" and is currently showing the configuration for "Ethernet Port 0". The configuration is divided into several sections:

- Port Configuration:** Set to "Static".
- Connection Status:** Not Connected.
- IPv4 Assignments:**

Address	Subnet Mask	Gateway	Broadcast
1.1.1.251	255.255.255.0	1.1.1.1	1.1.1.255
- IPv6 Assignments:**

IPv6 Mode	Address	Scope
Static	fd6b:fd64:9e0c::128	Global
	fd6b:fd64:9e0c::	Global
- IPv4 Address:** <IPv4 address to ping> with a "Ping IPv4" button.
- IPv6 Address:** <IPv6 address to ping> with a "Ping IPv6" button.

A red circle highlights the "Ethernet Port 0" tab in the configuration area.

## 7.5.3 get network eth<x>

```
TS200 Configuration Commands
>
>
> get network eth0

Current settings for eth0:
  Status: Not Connected
  IPv4Mode: Static
  Address: 1.1.1.251
  Mask: 255.255.255.0
  Broadcast: 1.1.1.255
  Gateway: 1.1.1.1
  IPv6Mode: Static
  IPv6 Addr: fd6b:fd64:9e0c::/128 Scope:Global
>
>
```

The screenshot displays the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a "Logout" link, a "Disable auto-logout" checkbox, and a welcome message: "Welcome *trimblesuper*. You have *super* access rights." Below this is the Trimble logo and the product name "Thunderbolt NTP TS200".

The main content area is titled "Ethernet Configuration" and is divided into three tabs: "Ethernet Port 0" (selected), "Ethernet Port 1", and "Management Port".

Under the "Ethernet Port 0" tab, the configuration is as follows:

- Port Configuration:** Static (dropdown menu)
- Connection Status:** Not Connected
- IPv4 Assignments:**

Address	Subnet Mask	Gateway	Broadcast
1.1.1.251	255.255.255.0	1.1.1.1	1.1.1.255
- IPv6 Assignments:**

IPv6 Mode	Address	Scope
Static (dropdown menu)	fd6b:fd64:9e0c::/128	Global
	fd6b:fd64:9e0c::	Global
- IPv4 Address:** <IPv4 address to ping> (text input) with a "Ping IPv4" button below it.
- IPv6 Address:** <IPv6 address to ping> (text input) with a "Ping IPv6" button below it.

On the left side of the interface, there is a sidebar menu with the following categories:

- SYSTEM STATUS
- INTERFACE MANAGEMENT
  - Ethernet
  - VLAN
  - SNMP
  - Syslog
  - Serial Port
- SYNCHRONIZATION MANAGEMENT
- SECURITY MANAGEMENT
- SYSTEM

## 7.5.4 view network eth<x>

```

TS200 Configuration Commands
>
>
>
>
>
>
>
>
> view network eth2

Current stats for eth2:
  Status: Connected 100MB
  Mode: Static
Collisions: 0
  RX Bytes: 28 MB
  RX Packets: 106911
  RX Dropped: 4
  RX Errors: 0

  TX Bytes: 59 MB
  TX Packets: 106587
  TX Dropped: 0
  TX Errors: 0
>
  
```

Logout  Disable auto-logout
Welcome *trimblesuper*.  
You have *super* access rights.

# Thunderbolt NTP TS200

SYSTEM STATUS

- Alarms and Events
- System Info
- Timing
- GNSS
- Network

INTERFACE MANAGEMENT

SYNCHRONIZATION MANAGEMENT

SECURITY MANAGEMENT

SYSTEM MANAGEMENT

Network Information

Ethernet Port 0

Ethernet Port 1

Management Port

Ethernet Statistics

Statistic	Ethernet Port 0	Ethernet Port 1	Management Port
RX Bytes	N/A	N/A	29 MB
RX Packets	N/A	N/A	112632
RX Packets/Sec	N/A	N/A	2
RX Dropped	N/A	N/A	4
RX Errors	N/A	N/A	0
TX Bytes	N/A	N/A	63 MB
TX Packets	N/A	N/A	112645
TX Packets/Sec	N/A	N/A	3
TX Dropped	N/A	N/A	0
TX Errors	N/A	N/A	0
	1-second	10-seconds avg	
RX+TX Pkts/Sec	5	5	

## 7.6 VLAN Configuration

### 7.6.1 set network eth0 vlan

*Note: need to stop NTP first*

```
TS200 Configuration Commands
>
>
>
>
>
>
> set ntp eth0 disable
Updated NTP settings
>
> set network eth0 vlan 20,30
Interface: eth0
>
>
```

The screenshot shows the web interface for the Thunderbolt NTP TS200 device. At the top, there is a navigation bar with a "Logout" button, a "Disable auto-logout" checkbox, and a welcome message: "Welcome *trimblesuper*. You have *super* access rights." The main header features the Trimble logo and the text "Transforming the way the world works" followed by the device name "Thunderbolt NTP TS200".

The interface is divided into a left sidebar and a main content area. The sidebar contains a "SYSTEM STATUS" section and an "INTERFACE MANAGEMENT" section with a list of options: Ethernet, VLAN (highlighted), SNMP, Syslog, and Serial Port. The main content area is titled "VLAN Configuration" and has two tabs: "Ethernet Port 0" (active) and "Ethernet Port 1".

Under the "Ethernet Port 0" tab, there is a "VLAN Configuration" section. It includes a "VLAN ID Assignments" table with columns for VID1, VID2, VID3, and VID4. The first row contains the values 20, 30, VID3, and VID4. To the right of the table is a "Priority" field with the value 0. Below the table, a note states: "To remove a VLAN ID, delete it's entry from the list."

## 7.6.2 get network eth0

```
TS200 Configuration Commands
>
>
>
>
>
>
> get network eth0

Current settings for eth0:
  Status: Not Connected
  IPv4Mode: Static
  Address: 1.1.1.251
  Mask: 255.255.255.0
  Broadcast: 1.1.1.255
  Gateway: 1.1.1.1
  IPv6Mode: Static
  IPv6 Addr: fd6b:fd64:9e0c::/128 Scope:Global
  VLAN IDs: 20, 30

Current settings for eth0.20:
  Status: Not Connected
  IPv4Mode: Static
  Address: 15.15.15.15
  Mask: 255.255.255.0
  Broadcast: 15.15.15.255
  Gateway:
  IPv6Mode: Static

Current settings for eth0.30:
  Status: Not Connected
  IPv4Mode: Static
  Address: 15.15.15.15
  Mask: 255.255.255.0
  Broadcast: 15.15.15.255
  Gateway:
  IPv6Mode: Static
>
```

Logout  Disable auto-logout Welcome *trimblesuper*. You have *super* access rights.

# Thunderbolt NTP TS200

Transforming the way the world works

## VLAN Configuration

Ethernet Port 0 | Ethernet Port 1

**VLAN Configuration**

**VLAN ID Assignments**

VLAN ID	VID3	VID4	Priority
20	30		0

To remove a VLAN ID, delete it's entry from the list.

**VLAN Interface Assignments**

Edit	Interface	Address	Mask	Gateway
<input type="radio"/>	eth0.20	5.5.5.5	255.255.0.0	
<input type="radio"/>	eth0.30	15.15.15.25	255.255.0.0	

Only one VLAN Interface may be assigned or modified per 'Set' command.

**SYSTEM STATUS**

**INTERFACE MANAGEMENT**

- Ethernet
- VLAN**
- SNMP
- Syslog
- Serial Port

**SYNCHRONIZATION MANAGEMENT**

## 7.6.3 set network eth0.20

```

TS200 Configuration Commands
>
>
> set network eth0.20 addr 3.1.30.100 mask 255.0.0.0 gateway 3.1.30.1
Interface: eth0.20
Setting IP address to 3.1.30.100
Setting network mask to 255.0.0.0
Setting gateway address to 3.1.30.1
>
>
> set network eth0.30 addr 4.1.42.100 mask 255.0.0.0 gateway 4.1.42.1
Interface: eth0.30
Setting IP address to 4.1.42.100
Setting network mask to 255.0.0.0
Setting gateway address to 4.1.42.1
>
>

```

Logout  Disable auto-logout
Welcome *trimblesuper*.  
You have *super* access rights.

# Thunderbolt NTP TS200

SYSTEM STATUS

---

INTERFACE MANAGEMENT

Ethernet

VLAN

SNMP

Syslog

Serial Port

---

SYNCHRONIZATION

### VLAN Configuration

Ethernet Port 0
Ethernet Port 1

**VLAN Configuration**

**VLAN ID Assignments**

20	30	VID3	VID4	Priority
				0

To remove a VLAN ID, delete it's entry from the list.

**VLAN Interface Assignments**

Edit	Interface	Address	Mask	Gateway
<input checked="" type="radio"/>	eth0.20	3.1.30.100	255.0.0.0	3.1.30.1
<input type="radio"/>	eth0.30	15.15.15.25	255.255.0.0	

Only one VLAN Interface may be assigned or modified per 'Set' command.

Logout  Disable auto-logout
Welcome *trimblesuper*.  
You have *super* access rights.

# Thunderbolt NTP TS200

SYSTEM STATUS

---

INTERFACE MANAGEMENT

Ethernet

VLAN

SNMP

Syslog

Serial Port

---

SYNCHRONIZATION

### VLAN Configuration

Ethernet Port 0
Ethernet Port 1

**VLAN Configuration**

**VLAN ID Assignments**

20	30	VID3	VID4	Priority
				0

To remove a VLAN ID, delete it's entry from the list.

**VLAN Interface Assignments**

Edit	Interface	Address	Mask	Gateway
<input type="radio"/>	eth0.20	3.1.30.100	255.0.0.0	3.1.30.1
<input checked="" type="radio"/>	eth0.30	4.1.42.100	255.0.0.0	4.1.42.1

Only one VLAN Interface may be assigned or modified per 'Set' command.

## 7.6.4 get network eth0

```
TS200 Configuration Commands
>
>
>
> get network eth0

Current settings for eth0:
  Status: Not Connected
  IPv4Mode: Static
  Address: 1.1.1.251
  Mask: 255.255.255.0
Broadcast: 1.1.1.255
  Gateway: 1.1.1.1
  IPv6Mode: Static
IPv6 Addr: fd6b:fd64:9e0c::/128 Scope:Global
  VLAN IDs: 20, 30

Current settings for eth0.20:
  Status: Not Connected
  IPv4Mode: Static
  Address: 3.1.30.100
  Mask: 255.0.0.0
Broadcast: 3.255.255.255
  Gateway: 3.1.30.1
  IPv6Mode: Static

Current settings for eth0.30:
  Status: Not Connected
  IPv4Mode: Static
  Address: 4.1.42.100
  Mask: 255.0.0.0
Broadcast: 4.255.255.255
  Gateway: 4.1.42.1
  IPv6Mode: Static
>
>
>
```

Logout  Disable auto-logout Welcome *trimblesuper*.  
You have *super* access rights.

 **Thunderbolt NTP TS200**

Transforming the way the world works

### VLAN Configuration

Ethernet Port 0 | Ethernet Port 1

**VLAN Configuration**

**VLAN ID Assignments**

<input type="text" value="20"/>	<input type="text" value="30"/>	<input type="text" value="VID3"/>	<input type="text" value="VID4"/>	<input type="text" value="Priority"/>
---------------------------------	---------------------------------	-----------------------------------	-----------------------------------	---------------------------------------

To remove a VLAN ID, delete it's entry from the list.

**VLAN Interface Assignments**

Edit	Interface	Address	Mask	Gateway
<input type="radio"/>	eth0.20	3.1.30.100	255.0.0.0	3.1.30.1
<input type="radio"/>	eth0.30	4.1.42.100	255.0.0.0	4.1.42.1

Only one VLAN Interface may be assigned or modified per 'Set' command.



## 7.8.3 view input

```

TS200 Configuration Commands
>
> set input gnss disable
> set input gnss enable
>
> view input

GNSS : reference
qualified: No
level: 0
No data available
> view input

GNSS : reference
qualified: No
level: 0
No data available
> view input

GNSS : reference
qualified: No
level: 0
No data available
> view input

GNSS : reference
qualified: No
level: 0
offset: +9.68 ns
mean: +0.44 ns
sigma: 72.07 ns
freq: -0.722 ppt
>

```

Logout  Disable auto-logout
Welcome *trimblesuper*.  
You have *super* access rights.

# Thunderbolt NTP TS200

SYSTEM STATUS

Alarms and Events

System Info

Timing

GNSS

Network

---

INTERFACE MANAGEMENT

---

SYNCHRONIZATION MANAGEMENT

---

SECURITY MANAGEMENT

### Timing Information

Timing Status
NTP Status

**Input Status**

Sync Source  
GNSS

**Sync Source Statistics**

Sync Source	Phase Offset	Mean	Sigma	Freq Offset
GNSS	-15.673 ns	0.488 ns	3.762 ns	-0.00045 ppb

**Output Status**

Sync Out  
10MHz

**Control Loop Status**

Loop State	Holdover	Phase Offset	Freq Offset	Delta Freq
Lock	21 seconds	-9.743ns	-3.06462e-07	-2.311e-11

**Realtime Graph View**

Sync Source ▼
Graph Type ▼
Close Graph

# 7.9 Antenna Cable Delay and BNC Port Output

## 7.9.1 set gnss adelay 40

```
TS200 Configuration Commands
> get gnss
Constellation: GPS|GLO
Elevation mask: 10.0 deg
Signal level mask: 0.00 db/Hz
PDOP mask: 3.0
Antenna delay: 0 ns
Pos: auto
Survey length: 2000
Antenna: Off
>
>
> get gnss
Constellation: GPS|GLO
Elevation mask: 10.0 deg
Signal level mask: 0.00 db/Hz
PDOP mask: 3.0
Antenna delay: 0 ns
Pos: auto
Survey length: 2000
Antenna: Off
> set gnss adelay 40
>
> get gnss
Constellation: GPS|GLO
Elevation mask: 10.0 deg
Signal level mask: 0.00 db/Hz
PDOP mask: 3.0
Antenna delay: 40 ns
Pos: auto
Survey length: 2000
Antenna: Off
>
```

The screenshot shows the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a 'Logout' button, a 'Disable auto-logout' checkbox, and a welcome message: 'Welcome trimblesuper. You have super access rights.' Below this is the Trimble logo and the title 'Thunderbolt NTP TS200'. The main content area is titled 'GNSS Configuration' and contains several sections: 'Constellation Selection' with checkboxes for GPS, GLONASS, Beidou, Galileo, and QZSS; 'Position Settings' with a 'Positioning Mode' dropdown set to 'Automatic'; and various input fields for 'Survey Length (secs)', 'Latitude (degrees)', 'Longitude (degrees)', 'Height (meters)', 'Elevation Mask', 'PDOP Mask', 'Signal Level Mask', 'Receiver Status', 'Receiver Mode', and 'Antenna Delay (ns)'. A red circle highlights a small icon in the top right corner of the configuration panel. On the left side, there is a sidebar menu with categories: SYSTEM STATUS, INTERFACE MANAGEMENT, SYNCHRONIZATION MANAGEMENT (highlighted), NTP, GNSS, Output, and SECURITY MANAGEMENT.

## 7.9.2 set output 10MHz

```
TS200 Configuration Commands
>
>
> get output
  BNC output: PPS
Width: 1000 ns
Delay: 0 ns
>
> set output 10MHz
>
> get output
  BNC output: 10MHz
Width: 1000 ns
Delay: 0 ns
>
>
>
```

The screenshot displays the web interface for the Thunderbolt NTP TS200. At the top, there is a navigation bar with a "Logout" button, a "Disable auto-logout" checkbox, and a welcome message: "Welcome *trimblesuper*. You have *super* access rights." Below this is the Trimble logo and the product name "Thunderbolt NTP TS200".

The main content area is titled "Output Configuration" and is divided into three columns:

- Output Ports:** A dropdown menu labeled "Sync Out" is currently set to "PPS". Other options include Off, Low, High, PPS, Even, Periodic, and 10MHz.
- Output Settings:** Two input fields are present: "Width (ns)" with a value of 1000, and "Delay (ns)" with a value of 0.
- Periodic Settings:** Three input fields are present: "Width (ns)" with a value of 1000, "Period (seconds)" with a value of 10, and "Value (0 - Period-1)" with a value of 0.

On the left side of the interface, there is a sidebar menu with the following categories:

- SYSTEM STATUS
- INTERFACE MANAGEMENT
- SYNCHRONIZATION MANAGEMENT
  - NTP
  - GNSS
  - Output (highlighted)

## 7.9.3 config firmware list

```
TS200 Configuration Commands
>
>
> config firmware list
Available firmware update packages:
P0      : 20171003-0.0.7.0.pkg
P1      : 20171212-0.0.7.0+.pkg
P2      : 20180204-0.0.9.0.pkg

Available GNSS update firmware:
G0      : ResSMT360_v1_03.bin
G1      : ResSMT360_v1_04.5.bin
>
>
```

Logout  Disable auto-logout Welcome *trimblesuper*.  
You have *super* access rights.

**Trimble** Transforming the way the world works

# Thunderbolt NTP TS200

## System Configuration

SYSTEM STATUS

INTERFACE MANAGEMENT

SYNCHRONIZATION MANAGEMENT

SECURITY MANAGEMENT

**SYSTEM MANAGEMENT**

Alarm  
System

System Configuration | **System Firmware**

Current System Version	Current GNSS Version	Current FPGA Version
20180204-0.0.9.0	20170515-1.4.0.0	18.3.15

Firmware Patch Staging

Choose File | No file chosen

Upload Patch File | Reset Upload

System Patches | GNSS Patches

- 20171003-0.0.7.0.pkg
- 20171212-0.0.7.0+.pkg
- 20180204-0.0.9.0.pkg
- ResSMT360\_v1\_03.bin
- ResSMT360\_v1\_04.5.bin



## Chapter 8: VLANs

In this chapter:

VLAN Overview

Configuring with CLI commands

Configuring with Web Interface

Configuring one VLAN ID

Adding another VLAN ID

Procedure to remove all VLAN IDs

This chapter describes the VLAN setting procedure for Thunderbolt NTP Time Server Clock TS200.

## 8.1 VLANs Overview

Thunderbolt NTP Time Server Clock TS200 supports up to 4 VLANs on each port in total 8 VLAN. Each VLAN must have its own address and subnet. There is no default VLAN configuration. These VLANs can be configured with a default gateway. All VLANs configuration can be deleted with a CLI command “set network eth0/1 vlan -1”.

## 8.2 Configuring VLAN support with CLI commands

set network eth0/1 vlan ID1,ID2,...

This command allows to add up to 4 different VLAN IDs for each Ethernet port.

set network eth0/1.ID addr x.x.x.x mask y.y.y.y gateway z.z.z.z

This command allows to configure IP address, subnet mask and gateway address for each VLAN ID

set network eth0/1 vlan -1

This command allows to disable VLAN on the Ethernet port selected.

Please use the special ID of '-1'.

get network eth0/1


This command allows to show Ethernet port configuration including VLAN configuration on the Ethernet port selected.

**NOTE: When changes are applied to any Ethernet port, it takes up to 30 seconds to see changes in Ethernet port configuration.**

## 8.3 Configuring VLAN with Web Interface

Connect to TS200 using web interface using https. Then login with a proper username with correct privileges like admin or super access level.

Then click on “INTERFACE MANAGEMENT” and then click on “VLAN”.



The screenshot displays the web interface for a Thunderbolt 200 device. At the top, there is a navigation bar with a "Logout" button and a "Disable auto-logout" checkbox. A welcome message reads: "Welcome *trimblesuper*. You have *super* access rights." The main header shows the "Trimble" logo and the device name "Thunderbolt 200".

The left sidebar contains several menu items: "SYSTEM STATUS", "INTERFACE MANAGEMENT" (highlighted), "Ethernet", "VLAN" (highlighted), "SNMP", "Syslog", "Serial Port", "SYNCHRONIZATION MANAGEMENT", "SECURITY MANAGEMENT", and "SYSTEM MANAGEMENT".

The main content area is titled "VLAN Configuration" and has two tabs: "Ethernet Port 0" and "Ethernet Port 1". Under "Ethernet Port 1", there is a "VLAN Configuration" section with "VLAN ID Assignments". It features input fields for "333", "444", "VID3", "VID4", and "Priority" (set to "0"). A note below states: "To remove a VLAN ID, delete it's entry from the list."

Below this is the "VLAN Interface Assignments" section, which contains a table:

Edit	Interface	Address	Mask	Gateway
<input type="radio"/>	eth1.333	21.134.199.220	255.255.255.248	
<input type="radio"/>	eth1.444	11.34.99.20	255.255.255.248	

A note at the bottom of the table states: "Only one VLAN Interface may be assigned or modified per 'Set' command."

In order to do changes, it is required to click on “Configure” icon  and in order to apply the changes, it is required to click on “Set” icon .

**Note – VLAN IDs 1 and 2 are reserved, you cannot use them.**

It is required to add the VLAN ID, Priority (0 is the highest priority), the IP address and subnet mask.

## 8.4 Configuring one VLAN ID

In order to provide configuration steps, some examples will be used.

### Example 1:

Use the following procedure to configure a VLAN on the eth0 port, an ID 452, IPv4 address of 21.153.200.230, a netmask of 255.255.255.248, and a gateway of 21.153.200.225:

- Login with username with admin or super level.
- Disable NTP services in order to configure any VLAN ID

```
set ntp eth0 disable
```
- Type

```
set network eth0 vlan 452
```
- Press Enter
- Type

```
set network eth0.452 addr 21.153.200.230 mask 255.255.255.248 gateway 21.153.200.225
```
- Press Enter
- Type

```
get network eth0
```
- Press Enter
- Console output is below

```
>
>
> get network eth0

Current settings for eth0:
  Status: Connected 1000MB
  Mode: Static
  Address: 192.168.0.250
  Mask: 255.255.255.0
Broadcast: 192.168.0.255
  Gateway: 192.168.0.1
IPv6 Addr: fe80::217:47ff:fe7f:fdad/64 Scope:Link
  VLAN IDs: 452

Current settings for eth0.452:
  Status: Connected 1000MB
  Mode: Static
  Address: 21.153.200.230
  Mask: 255.255.255.248
Broadcast: 21.153.200.231
  Gateway: 21.153.200.225
IPv6 Addr: fe80::217:47ff:fe7f:fdad/64 Scope:Link
>
>
>
```
- It is now possible to enable again NTP service

```
set ntp eth0 enable
```

**Note – VLAN IDs 1 and 2 are reserved, you cannot use them.**

## 8.5 Adding another VLAN ID

In order to provide configuration steps, some examples will be used.

### Example 2:

Use the following procedure to add a VLAN ID 444 on Ethernet eth1 port, this port has already a VLAN ID: VLAN ID 333

IP address 21.134.199.220

Subnet mask 255.255.255.248

Gateway 21.134.199.215

The new VLAN information will be

VLAN ID 444

IP address 11.34.99.20

Subnet mask 255.255.255.248

Gateway 11.34.99.15

- Login with username with admin or super level.
- Disable NTP services in order to configure any VLAN ID

```
set ntp eth1 disable
```
- Type

```
get network eth1
```
- Press Enter
- Console output is below

```
>  
> get network eth1
```

```
Current settings for eth1:
```

```
  Status: Connected 1000MB  
  Mode: Static  
  Address: 4.4.4.4  
  Mask: 255.255.255.0  
Broadcast: 4.4.4.255  
  Gateway:  
IPv6 Addr: fe80::217:47ff:fe7f:fd4e/64 Scope:Link  
  VLAN IDs: 333
```

```
Current settings for eth1.333:
```

```
  Status: Connected 1000MB  
  Mode: Static  
  Address: 21.134.199.220  
  Mask: 255.255.255.248  
Broadcast: 21.134.199.223  
  Gateway: 21.134.199.215  
IPv6 Addr: fe80::217:47ff:fe7f:fd4e/64 Scope:Link
```

```
>  
>  
>
```

- Type `set network eth1 vlan 333,444`

- Press Enter

- Type `get network eth1`

- Press Enter

- Console output is below

```
>
> get network eth1

Current settings for eth1:
  Status: Connected 1000MB
  Mode: Static
  Address: 4.4.4.4
  Mask: 255.255.255.0
Broadcast: 4.4.4.255
  Gateway:
IPv6 Addr: fe80::217:47ff:fe7f:fdde/64 Scope:Link
  VLAN IDs: 333, 444
```

```
Current settings for eth1.333:
  Status: Connected 1000MB
  Mode: Static
  Address: 21.134.199.220
  Mask: 255.255.255.248
Broadcast: 21.134.199.223
  Gateway: 21.134.199.215
IPv6 Addr: fe80::217:47ff:fe7f:fdde/64 Scope:Link
```

```
Current settings for eth1.444:
  Status: Connected 1000MB
  Mode: Static
  Address: 21.134.199.220
  Mask: 255.255.255.248
Broadcast: 21.134.199.223
  Gateway: 21.134.199.215
IPv6 Addr: fe80::217:47ff:fe7f:fdde/64 Scope:Link
>
```

- Type `set network eth1.444 addr 11.34.99.20 mask 255.255.255.248 gateway 11.34.99.15`

- Press Enter

- Type `get network eth1`

- Press Enter

- Console output is below

```
>
> get network eth1

Current settings for eth1:
  Status: Connected 1000MB
  Mode: Static
  Address: 4.4.4.4
  Mask: 255.255.255.0
Broadcast: 4.4.4.255
  Gateway:
IPv6 Addr: fe80::217:47ff:fe7f:fdde/64 Scope:Link
  VLAN IDs: 333, 444
```

```
Current settings for eth1.333:
  Status: Connected 1000MB
  Mode: Static
  Address: 21.134.199.220
  Mask: 255.255.255.248
Broadcast: 21.134.199.223
  Gateway: 21.134.199.215
IPv6 Addr: fe80::217:47ff:fe7f:fd4e/64 Scope:Link

Current settings for eth1.444:
  Status: Connected 1000MB
  Mode: Static
  Address: 11.34.99.20
  Mask: 255.255.255.248
Broadcast: 11.34.99.23
  Gateway: 11.34.99.15
IPv6 Addr: fe80::217:47ff:fe7f:fd4e/64 Scope:Link
2017-07-12T07:38:17.731Z: Set alarm 20, 'Eth-Port0-Down'
2017-07-12T07:38:18.744Z: Set alarm 21, 'Eth-Port1-Down'
2017-07-12T07:38:25.265Z: Clear alarm 21, 'Eth-Port1-Down'
>
>
>
>
```

- It is now possible to enable again NTP service  
`set ntp eth1 enable`

## 8.6 Procedure to remove all VLAN IDs

The command is used to disable all VLAN configuration on a specific Ethernet port:

```
set network eth0/1 vlan -1
```



## Appendix A: SNMP Traps

In this appendix:

[SNMP Traps](#)

This appendix list the available  
alarms through SNMP trap in  
Thunderbolt® NTP Time Server  
Clock

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 0 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 0, GNSS-Comm-E1 (CRI)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 1, GNSS-Comm-E2 (CRI)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 2 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 2, GNSS-Comm-Loss (CRI)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 3 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 3, GNSS-Ant-Shorted (MAJ)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 4 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 4, GNSS-Ant-Open (MAJ)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 5 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 5, GNSS-Track-No (MIN)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 6 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 6, PTP-PPS-Loss (MIN)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 7 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 7, GNSS-PPS-Loss (MIN)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 8 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 8, Time-Sync-Bad (MAJ)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 9 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 9, Freq-Range-Bad (CRI)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 11 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 11, Time-Set-Bad (MIN)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 12 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 12, Freq-Loop-Unlock (MIN)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 13 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 13, Freq-Hold-Exceed (MAJ)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 14 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 14, PPS-Sync-Bad (MAJ)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 15 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 15, Freq-Out-Bad (MAJ)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 16 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 16, PTP-System-Bad (CRI)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 17 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 17, FPGA-Load-Bad (CRI)"

TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmEchoNotification TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmNumber = INTEGER: 18 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationAlarmActivity = INTEGER: 1 TRIMBLE-TBOLT2-ALARM-MIB::trimbleEchoAlarmNotificationDescr = STRING: "Set alarm 18, GNSS-Pos-Integrity (MIN)"

## Appendix B: Alarms

In this appendix:

List of alarms

This appendix lists the available alarms in Thunderbolt® NTP Time Server Clock

Alarm	Alarm Desc	Level	Set Time	Clear Time	Description	How to resolve
0	GNSS-Comm-E1	CRI	0	0	An internal GNSS communication alarm that indicates that the system is unable to process character from the GNSS receiver as fast as it is being generated. This alarm should never be present and is used as a BIST (build-in self-test) indication of a hardware failure.	Call Trimble Technical Support
1	GNSS-Comm-E2	CRI	0	0	An internal GNSS communication alarm that indicates that the system is unable to process GNSS response data from the GNSS receiver as fast as it is being generated. This alarm should never be present and is used as a BIST (build-in self-test) indication of a hardware issue. This may be caused by excessive processing load on the system (denial of service attack).	Call Trimble Technical Support
2	GNSS-Comm-Loss	CRI	2	5	An indication that complete communication has been lost to the GNSS receiver. This may be due to a bad receiver, or a bad receiver firmware update was recently applied. If an update was recently applied the system administrator can try loading the firmware again, or loading a previous firmware version. Note that this alarm may be set on startup as the GNSS receiver is restarting.	Call Trimble Technical Support

3	GNSS-Ant-Shorted	MIN	0	2	An indication of an over-current indication on the antenna feed. This is an indication that the unit may not be able to acquire satellites as the antenna may be damaged. The condition should be remedied before continuing operation.	Disconnect the antenna cable from the unit and verify the alarm clears; The GNSS-Ant-Open alarm should become active. Replace antenna, verify the alarm is clear; if the alarm is still active replace the antenna cable.
4	GNSS-Ant-Open	MIN	0	2	An indication of an under-current indication on the antenna feed. This may be 'normal' if the antenna input is from a splitter or another device that blocks DC power. In this condition the antenna must be externally powered. It is acceptable for the administrator to set the alarm level for this alarm to 'Ign' to clear this alarm condition.	Verify that the antenna and antenna cable are securely fastened. If they are, replace antenna.
5	GNSS-Track-No	MIN	0	2	An indication that the system is unable to track any satellites at this time. This may be a 'normal' condition the event of poor satellite coverage. For this reason it is acceptable for this alarm to have a set and clear time associated with it to alleviate 'nuisance' type alarms.	This alarm is active whenever the system is powered-up or antenna is disconnected. Ensure the antenna is connected and the view of the sky is good.
6	GNSS-PPS-Loss	MIN	0	10	An indication that the system is not detecting the 1PPS signal from the GNSS system. This may be due to loss of GNSS signaling, or invalid GNSS data. The unit will enter into holdover in this condition.	if the alarm persists for longer than 60 minutes, call Trimble Technical Support
7	Time-Sync-Bad	MAJ	2	10	An indication that the phase relationship for the NTP vs the time/frequency control is out of specification. This occurs during startup, while the phase is being aligned to GNSS, but it can also be an	if the alarm persists for longer than 60 minutes, call Trimble Technical Support

					indication of extreme environmental changes that are causing the system phase to move faster than the control loop is able to compensate. This condition should clear when the conditions settle.	
<b>8</b>	Freq-Range-Bad	CRI	0	10	is set when the frequency control reaches a limit of 20E-6. Unless this is during a test condition, or the unit is tracking a simulator that is not locked to a valid frequency source, this is an indication of a failure of the frequency control and the unit requires service.	if the alarm persists for longer than 60 minutes, call Trimble Technical Support
<b>9</b>	GNSS-Time-Bad	MIN	0	0	indicates that the GNSS system is indicating that the time has not been acquired from the satellites. This alarm will clear when the unit begins tracking valid satellite signals.	if the alarm persists for longer than 60 minutes, call Trimble Technical Support
<b>10</b>	Freq-Loop-Unlock	MIN	2	5	an indication that the frequency control loop has not yet established a locking condition. This is set during startup, while the control loop is settling, but may also be set during recover from holdover or in the event of severe environmental changes. This alarm will clear when the unit has achieved lock to the GNSS signal.	if the alarm persists for longer than 60 minutes, call Trimble Technical Support
<b>11</b>	Freq-Hold-Exceed	MAJ	0	0	is set when the unit is in the halt condition (no compensation during holdover), or the unit has been in a holdover condition for more than 24 hours.	if the alarm persists for longer than 60 minutes, call Trimble Technical Support
<b>12</b>	PPS-Sync-Bad	MAJ	5	10	is set when the PPS output (timing) from the system will not meet specification. This	if the alarm persists for longer than 60 minutes, call Trimble Technical Support

					may occur during extreme environmental changes and should clear when the system becomes stable.	
<b>13</b>	Freq-Out-Bad	MAJ	0	10	is set when the frequency output from the unit is adversely affecting performance. This may occur during extreme environmental changes and should clear when the system becomes stable.	if the alarm persists for longer than 60 minutes, call Trimble Technical Support
<b>14</b>	FPGA-Load-Bad	CRI	0	0	is set if the FPGA hardware image is too old for this firmware. The hardware should be updated with the config firmware command.	Call Trimble Technical Support
<b>15</b>	GNSS-Pos-Integrity	MIN	60	2	is set if the unit has not tracked enough satellites to allow for a validation of the position. This is cleared once the unit has validated the position. When the position is not known then the integrity of the timing solutions may be suspect.	if the alarm persists for longer than 60 minutes, call Trimble Technical Support
<b>16</b>	UTC-Corr-Unk	MAJ	0	0	is set if the unit does not have the UTC corrections from the GNSS system. This is cleared once the UTC corrections have been acquired from the GNSS system. This is an issue because NTP requires the UTC correction be transmitted on most systems so that the sync to UTC may be established.	if the alarm persists for longer than 60 minutes, call Trimble Technical Support
<b>17</b>	Eth-Port0-Down	MAJ	0	2	is set when Ethernet Port 0 is not operational. Note that, if the user commands the port to be disabled, this alarm is cleared. The alarm is set only when it is a fault condition and disabling of the port is not considered a fault.	Check to make sure the ethernet cable is connected at both ends. If this port is not to be used, then Ethernet Port can be disabled to clear this alarm.

18	Eth-Port1-Down	MAJ	0	2	is set when Ethernet Port 1 is not operational. Note that, if the user commands the port to be disabled," this alarm is cleared. The alarm is set only when it is a fault condition and disabling of the port is not considered a fault.	Check to make sure the ethernet cable is connected at both ends. If this port is not to be used, then Ethernet Port can be disabled to clear this alarm.
19	Eth-Mgmt-Down	MAJ	0	2	is set when Ethernet Port 2 is not operational. Note that, if the user commands the port to be disabled," this alarm is cleared. The alarm is set only when it is a fault condition and disabling of the port is not considered a fault.	Check to make sure the ethernet cable is connected at both ends. If this port is not to be used, then Ethernet Port can be disabled to clear this alarm.
20	Eth-Same-Subnet	CRI	0	0	is set when any of the Ethernet ports are on the same subnet. This is problematic for PTP because PTP requires that the data is timestamped on the physical port which received the packet. Due to the routing and socket parsing within the network, if 2 ports have the same subnet, the data may actually be received on a different physical port. For PTP that would then mean that the timestamp was for a completely different path than what may be intended. Worse yet, if a timing port and the management port are on the same subnet then the PTP traffic may be received over the management port, which does not have the hardware timestamping capabilities. That makes all timestamps in the communication '0'. NOTE: The above is only an issue if you are using PTP as unicast on an IPv4 network. If you are	Configure the ethernet ports to use different subnets.

					multicast, or using IPv6 or 802.3 then this alarm can be safely ignored.	
<b>21</b>	Time-Set-Bad	CRI	0	0	indicates that the hardware time has never been set to agree with a valid phase source. This occurs only on startup and will clear as soon as the unit has a valid phase time to establish a valid time reference.	if the alarm persists for longer than 60 minutes, call Trimble Technical Support

**Note 1:** "Level" means default set level of alarm. It has several levels and user can choose one of options below.

- IGN : This alarm condition is ignored. No indication given.
- NFY : This alarm condition is a notification only.
- MIN : This is a minor alarm condition.
- MAJ : This is a major alarm condition.
- CRI : This is a critical alarm condition.



# Contact Information

## **NORTH AMERICA**

Trimble Inc.  
Corporate Headquarters  
935 Stewart Drive  
Sunnyvale, CA 94085  
+1-800-787-4225  
+1-408-481-7741

## **EUROPE**

Trimble Inc Europe Phone: +46-8-  
622-12-79

## **KOREA**

Trimble Export Ltd, Korea Phone:  
+82-2-555-5361

## **CHINA**

Trimble Navigation Ltd, China Phone: +86-10-8857-  
7575

